


**A** mm (inch)



**B**

B/C = Abluft / Return

A = Zuluft / Supply

**C**

