

SDC-H1T1 Duct Humidity and Temperature Transmitter


Features

- Replaceable sensor element
- Humidity and temperature measurement for air ducts
- Minimum and maximum value memory
- 0...10 V, 0...20 mA or 2...10 V, 4...20 mA measuring signals selectable with jumpers
- Optional alternative signal ranges programmable
- Selectable averaging signal
- Optional LCD display (OPC-S) or external display (OPA-S)
- Status LED

Applications

- Humidity and temperature measurement for supply and return air ducts in heating, ventilation and air conditioning applications.
- Recording of minimum and maximum values for critical environments
- Supervision of critical humidity and temperatures

Humidity and temperature transmitter



Standard output signal range and types may be selected by jumpers. Standard signal ranges are: 0...10 VDC, 0...10 VDC, 4...20 mA and 0...20 mA. Other ranges can be defined by using a programming tool (OPA-S or OPC-S). A version with display is possible by ordering the integrated display accessory OPC-S.



Using the programming tool, the user has the option to read out and reset minimum and maximum values. The minimum and maximum values may as well be used as output signals. The minimum and maximum values are saved into the EEPROM and are available after a power interruption.

Ordering

Per default a sensor element with 3% RH accuracy and a PG9 cable gland for cables \emptyset 4 – 8 mm (AWG 6 – 1) (item name AMC-1) is included. Contact your local sales contact to order different probe length, sensing elements with different accuracies or if you prefer a sensor with conduit connectors or a built in display module.

Signal converter

Item Name	Item Code	Description/Option	
SDC-H1T1-08-A3-1	40-30 0150	Signal converter for duct mounting: probe length 8 cm (3"), incl. cable gland AMC-1 and a sensor AES3-HT-A3	
SDC-H1T1-16-A3-1	40-30 0151	Signal converter for duct mounting: probe length 16 cm (6.2"), incl. cable gland AMC-1 and a sensor AES3-HT-A3	
SDC-H1T1-24-A3-1	40-30 0110	Signal converter for duct mounting: probe length 24 cm (9.4"), incl. cable gland AMC-1 and a sensor AES3-HT-A3	
SDC-H1T1-x-A3-1-W0	40-30 0xxx-0	0 Temperature Range: -4060°C (-40140°F) (default)	
SDC-H1T1-x-A3-1-W1	40-30 0xxx-1	1 Temperature Range: -3535°C (-3195°F)	
SDC-H1T1-x-A3-1-W2	40-30 0xxx-2	2 Temperature Range: 050°C (32122°F)	
SDC-H1T1-x-A3-1-W3	40-30 0xxx-3	3 Temperature Range: Special – Specify in order	

Sensor element (for replacement only)

Item Name	Item Code	Humidity Accuracy [%RH]	Temperature Accuracy [K] @25 °C (77 °F)	Description/Option
AES3-HT-A2	40-50 0102	± 2%	± 0.3°	
AES3-HT-A3	40-50 0103	± 3%	± 0.4°	Humidity - temperature sensor element
AES3-HT-A5	40-50 0104	± 5%	± 0.5°	

Accessories

Item Name	Item Code	Description/Option
OPC-S	40-50 0029	Built in display and programming module
OPA-S	40-50 0006	External display module
AMS-1	20-10 0116	Weather shield to protect the sensor element
AMC-2	40-50 0074	Conduit connector NPT 1/2







Technical specification

Warning! Safety advice! This device is intended to be used for comfort applications. Where a device failure endangers human life and/or property, it is the responsibility of the owner, designer and installer to add additional safety devices to prevent or detect a system failure caused by such a device failure. The manufacturer of this device cannot be held liable for any damage caused by such a failure. Failure to follow specifications and local regulations may endanger life, cause equipment damage and void warranty.


Power supply	Operating voltage Transformer		24 V AC 50/60 Hz \pm 10%, 24 VDC \pm 10% SELV to HD 384, Class II, 48 VA max.	
	Power consumption		Max. 2 VA	
	Terminal connectors		For wire 0.342.5 mm ² (AWG 2412)	
Sensing probe	Humidity sensor		Capacity sensor element	
	Range		0100% RH	
	Measuring accuracy		See Figure 1	
	Hysteresis		± 1%	
	Repeatability		± 0.1%	
	Stability		< 0.5% / year	
	Temperature sensor		Bandgap sensor	
	Range		-4070 °C (-40158 °F)	
	Measuring accuracy		See Figure 2	
	Repeatability		± 0.1 °C, ± 0.2 °F	
Signal outputs	Analog outputs		500.401/ 0.00	
	Output signal		DC 0-10 V or 020 mA	
	Resolution		10 Bit, 9.7 mV, 0.019.5 mA	
	Maximum load		Voltage: ≥1kΩ Current: ≤250Ω	
Environment	Operation		To IEC 721-3-3	
	Climatic conditions		class 3 K5	
	Temperature		-4070 °C (-40158 °F)	
	Humidity		<95% R.H. non-condensing	
	Transport & storage		To IEC 721-3-2 and IEC 721-3-1	
	Climatic conditions		class 3 K3 and class 1 K3	
	Temperature		-4080 °C (-40176 °F) <95% R.H. non-condensing	
	Humidity Mechanical conditions		class 2M2	
Standards	conformity		CIG55 21 12	
Stanuarus	EMC directive		2004/108/EC	
	Low voltage dir	ective	2006/95/EC	
			2000/95/20	
	Product standards automatic electrical controls for household and similar use		EN 60 730 -1	
	Electromagnetic compat		Emissions: EN 60 730-1	
	domestic and industrial	•	Immunity: EN 60 730-1	
			IP60	
	Degree of protection to EN 60529 Mounted probe down with AMS-1		IP60 IP63	
	· · · · · · · · · · · · · · · · · · ·	ui Al·i3-1		
	Safety class		III (IEC 60536)	
General	Housing materials	Cover, back part Filter material	PC+ABS (UL94 class V-0) PTFE coated 1µm pores	
	Dimensions (H x W x D)	Transmitter case	68 x 91 x 47 mm (2.7" x 3.7" x 1.9")	
	(X 2)	Probe	Ø 14 x 77/157 mm (Ø 0.55 x 3/6.2")	
		SDC-H1T1-08-A3-1	227g (7.9 oz)	
	Weight (incl. package)	SDC-H111-08-A3-1	7770 (7 9 07)	








Dimensions mm(inch)





Installation and storage

Mounting location

The transmitter should be installed on the duct in an area where the air stream is well mixed:

- Locate a supply air sensor two or three meters downstream from the nearest fan and coil.
- Mount the return air sensor close to the air inlet but downstream from a return fan if one is present.

Mounting instruction / replacing the sensor element

See installation sheet no. 70-000525 (www.vectorcontrols.com).

Warning about storage, packaging and usage environment

The sensing part is a polymer, which measures the humidity in the ambient air. For proper sensor operation some mandatory precautions need to be taken during storage, packaging and usage.

The transmitter and its sensing element should not be packaged, stored or used in out-gassing plastic materials, which could cause sensor contamination. In particular, it is recommended not to use any glue or adhesive tapes (Sellotape, Scotch-Tape, Tesa-Film, etc.) within the package or close proximity of the sensor. Foamed materials often cause contamination problems and should not be used to package the transmitter. Best packaging material is a simple cardboard box or a deep-drawn plastic case in a cardboard box.

Configuration

The transmitter can be adapted to fit perfectly into any application by adjusting the software parameters. The parameters are set with the operation terminals OPA-S or OPC-S. The OPA-S may also be used as remote indicator.

Input configuration

Parameter	Description	Range	Default
IP 00	TI1: Celsius or Fahrenheit, C = OFF, F = ON	ON, OFF	OFF
IP 01	TI1: Samples taken for averaging control signal	1255	10
IP 02	TI1: Calibration	-1010	0
IP 03	TI1: Minimum temperature	-40215 °C/F	0 °C
IP 04	TI1: Maximum temperature	-40215 °C/F	50°C
IP 05	H1: Show Percent	ON, OFF	ON
IP 06	H1: Samples taken for averaging control signal	1255	10
IP 07	H1: Calibration	-1010%	0

Output configuration

Parameter	Description	Range	Default
OP 00	AO1: Humidity: Configuration of output signal:	0 - 2	0
	0 = Feedback humidity input,		
	1 = Feedback humidity minimum value		
	2 = Feedback humidity maximum value		
OP 01	AO1: Humidity: Minimum limitation of output signal	0 - Max %	0%
OP 02	AO1: Humidity: Maximum limitation of output signal	Min - 100%	100%
OP 03	AO2: Temperature: Configuration of output signal:	0 - 2	0
	0 = Feedback temperature input,		
	1 = Feedback temperature minimum value		
	2 = Feedback temperature maximum value		
OP 04	AO2: Temperature: Minimum limitation of output signal	0 - Max %	0%
OP 05	AO2: Temperature: Maximum limitation of output signal	Min - 100%	100%

Output signal configuration

The analog output signal type may be configured with a jumper for 0-10 VDC or 0-20 mA control signals. The jumpers are located next to the terminal connector of each analog output. See table below for jumper placement. The factory setting is to 0-10 VDC.

Signal Type	JP1, JP2
0 - 10 V	(1-2)
0 – 20 mA	(2-3)





The signal range may be set with JP3 for both analog outputs. JP3 will only operate if the output range specified with OP01 and OP02 or OP04 and OP05 is left at the default position of 0...100%. With any other setting the position of JP3 has no influence and the range defined with the output parameters applies.

Signal Range	JP3
0 - 10 V, 0 - 20 mA	(1-2)
2 - 10 V, 4 - 20 mA	(2-3)

Jumper Settings

