





A mm (inch)




B



C




D 24V AC/DC




-MOD, -BAC

GND	V+	AO1	AO2	+	-	REF
1	2	3	4	5	6	7





8	9	10	11	12	13	14
UI4	UI5	UI6		DO1	DO2	DO

6 (0.02)









AEC-PM2 Programming






AEC-TRI



AEC-PM2





Display




AEC-PM2 plugged in






AEC-PM2 Auto Load




AEC-PM2



AEC-TRI



USB ↔ RS485



www.vectorcontrols.com

