

TCX2-Series Communicating Cabinet Mounted Universal Controller



Features

- Slave Modbus communication over RS485 RTU or ASCII
- RS485 bus communication with remote operation terminal OPA2-VC.
- Universal PI and/or binary control for any analog input/output signal and range.
- Multiple auxiliary functions: heat-cool auto changeover, automatic enable, set point compensation.
- Free heating or cooling with economizer function based on enthalpy or temperature.
- Differential, averaging, min and max functions
- Cascading of control loops.
- 8 freely assigned alarm conditions, selectable state of outputs on alarm condition.
- Transmitter function for inputs and set points.
- Functions for dehumidifying, set point shift and cascade control.
- Password protected programmable user and control parameters.
- Power Cap protected real-time clock with 48hr power backup.
- 7-day programmable schedules, with options including change of setpoints and direct position of manual outputs.
- Blue backlight.
- Clone parameter sets with plug-in memory AEC-PM1 – easily transport application parameters to multiple controllers.

Applications


- Heat exchangers
- Fan coil units
- Boilers
- VAV with reheat/recool
- Air handlers
- Fan, pump control
- Humidifiers
- Dehumidifiers
- Ventilation
- Radiant heating/cooling
- Pressurization
- Packaged terminal units

General

- The TCX2 is a programmable electronic universal controller with communication capabilities. Each control loop may use 2 PI sequences and 6 binary stages. The TCX2 comes with a built-in RS485 communication interface that allows peer-to-peer communication with an operation terminal such as OPA2-(2TH)-VC, or with a PC.
- Communication plug-ins allow for integration of the controller into a network. These modules are described in their own manual. Currently available are plug ins for BACnet and MODBUS.
- Flexible application configuration is made with a parameter-setting routine using the standard operation terminal.
- Complete parameter sets may be copied by use of an accessory called AEC-PM1 or exchanged with a PC using an RS485-USB converter and the EasySet program.

Name

T C X 2 - 4 0 8 6 3 - (M O D)



Com: Communication standard
Option: OP = with operation terminal
AO: 3 Analog outputs
DO: 6 Binary outputs
UI: 8 Universal inputs
DI: 0 Binary inputs
LP: 4 control loops



Ordering

Model	Item#	Display	Loop	Inputs	DO	AO	Description
TCX2-40863-MOD	40-11 0077	no	4	8 UI	6 Relays	3	Controller 24 V AC/DC, Modbus slave RS485
TCX2-40863-OP-MOD	40-11 0078	Yes	4	8 UI	6 Relays	3	Controller with display, Modbus slave RS485
OPA2-VC	40-50 0007	Yes	-	1T	-	-	Operation terminal
OPA2-2TH-VC	40-50 0023	Yes	-	1T+1H+2	-	-	Terminal with TH + 2 passive inputs
OPU2-2T-VC	40-50 0024	Yes	-	1T+2	-	-	Terminal with T + 2 passive inputs
OPU2-2TH-VC	40-50 0025	Yes	-	1T+1H+2	-	-	Terminal with TH + 2 passive inputs
OPT-2-VC	40-50 0098	YES	-	1NTC 1VDC	-	-	Terminal with touch screen, 1 NTC and 1 VDC input
AEC-PM1	40-50 0016	-	-	-	-	-	Plug-In memory module
AEX-MOD	40-50 0013	-	-	-	-	-	Modbus communication module
AEX-BAC	40-50 0044	-	-	-	-	-	BACnet MS/TP communication module
AMM-1	40-51 0022	-	-	-	-	-	Accessory for cabinet door mounting
AEC-USB-01	40-50 0046	-	-	-	-	-	Accessory to exchange parameter set with PC


Technical specifications

Important notice and safety advice


This device is for use as an operating controller. It is not a safety device. Where a device failure could endanger human life and property, it is the responsibility of the client, installer and system designer to add additional safety devices to prevent such a device failure. Ignoring specifications and local regulations may cause equipment damage and endangers life and property. Tampering with the device and misapplication will void warranty.

Power supply	Power requirements	24 VAC $\pm 10\%$, 50/60 Hz, 24VDC $\pm 10\%$ SELV to HD 384, Class II, 48VA max
	Power consumption	Max. 10 VA
	Electrical connection	Removable terminal connectors, wire 0.34...2.5 mm ² (AWG 24...12)
	Clock backup	Min. 48 hours
Signal inputs	Universal input	Input jumper set for voltage or current
	Input signal	0...10 V or 0...20 mA
	Resolution	9.76 mV or 0.019 mA (10 bit)
	Impedance	Voltage: 98k Ω Current: 250 Ω
	Passive input	Input jumper set to temperature (RT) or digital input (DI)
Signal outputs	Type & range:	NTC (Sxx-Tn10): -40...140 °C (-40...284 °F)
	Analog outputs:	DC 0...10 V or 0...20 mA
	Resolution	9.76 mV or 0.019 mA (10 bit)
	Maximum load	Voltage: $\geq 1k\Omega$ Current: $\leq 250\Omega$
	Relays outputs :	AC Voltage 0...250 VAC, full-load current 3A, locked-rotor 18A. DC Voltage 0...300 VDC, full-load current 3A, locked-rotor 18A.
Connection to remote terminal	Insulation strength between relays contacts and system electronics: between neighboring contacts:	4000V AC to EN 60 730-1 1250V AC to EN 60 730-1
	Hardware interface	RS485 in accordance with EIA/TIA 485
	Cabling	Twisted pair cable category 5 or 6
	Hardware interface	RS485 in accordance with EIA/TIA 485
	Max nodes per network	128
Network	Max nodes per segment	64 (Vector devices only)
	Conductors	Shielded Twisted Pair (STP) cable
	Impedance	100 - 130 ohm
	Nominal capacitance	100 pF/m 16 pF/ft. or lower
	Galvanic isolation	The communication circuitry is isolated
Modbus	Line termination	A line termination resistance (120 ohm) shall be connected between the terminals (+) and (-) of the furthestmost node of the network
	Network topology	Daisy chain according EIA/TIA 485 specifications
	Recommended maximum length per chain	1200 m (4000 ft.)
	Communication standard	Modbus (www.modbus.org)
	Default setting	19200 baud rate, RTU 8 data bits, 1 even parity bit, 1 stop bit
Environment	Communication speed	4800, 9600, 19200, 38400
	Protocol: Data bits	RTU - 8 data bits, ASCII - 7 data bits,
	Parity - stop bit	no parity - 2 stop, even or odd parity - 1 stop
	Operation	To IEC 721-3-3
	Climatic conditions	class 3K5
Standards	Temperature	0...50 °C (32...122 °F)
	Humidity	<85 % RH non-condensing
	Transport & storage	To IEC 721-3-2 and IEC 721-3-1
	Climatic conditions	class 3K3 and class 1K3
	Temperature	-25...70 °C (-13...158 °F)
General	Humidity	<95 % RH non-condensing
	Mechanical conditions	class 2M2
	 conformity EMC directive	2004/108/EC
	Low voltage directive	2006/95/EC
	Product standards	
Standards	Automatic electrical controls for household and similar use	EN 60 730 -1
	Special requirement on temperature dependent controls	EN 60 730 - 2 - 9
	Electromagnetic compatibility for industrial and domestic sector	Emissions: EN 60 730-1 Immunity: EN 60 730-1
	Degree of protection	IP00 to EN 60 529
	Pollution class	II (EN 60 730-1)
Standards	Safety class: Local regulations must be observed!	III (IEC 60536) if SELV is connected to DO II (IEC 60536) if line voltage is connected to DO.
	Overvoltage category	III (EN 60 730-1)
	 Product standards:	UL 873
	Temperature- indicating and -regulating equipment	CSA C22.2 No. 24
	Mark: c(ETL)us	Certified by Intertek: 4005917
General	Material	Fire proof ABS plastic (UL94 class V-0)
	Dimensions (H x W x D)	57 x 147 x 115 mm (2.3 x 5.8 x 4.5 in)
	Weight (including package)	TCX2-40863: 440g (15.2 oz) TCX2-40863-OP: 500g (17.6 oz)

Dimensions, mm (inch)



Connection diagram



Jumpers

Jumpers are located on the backside of the controller

AO: Selection of analog output type

Left position: voltage output (0...10 V)
factory default

Right position: current output (0...20 mA)

AO1	
0...10V	0...20mA
■	

UI: Selection of universal input type

Left position: voltage input (0...10 V)
factory default

Middle position: current input (0...20 mA)

Right position: RT or dry-contact

UI1		
0...10V	0...20mA	RT / DI
■		

Installation

See installation sheet no. 70-000599 (www.vectorcontrols.com).

Selection of actuators and sensors

Temperature sensors: Use Vector Controls NTC sensors to achieve maximum accuracy: SDB-Tn10-20 (duct), SRA-Tn10 (room), SDB-Tn10-20 + AMI-S10 as immersion sensor.

Actuators: Choose modulating actuators with an input signal type of 0-10 V DC or 4-20 mA (Min. and max. signal limitations may be set with parameters. 3-point actuators with constant running time are recommended.

Binary auxiliary devices (e.g. pumps, fans, on/off valves, humidifiers, etc.): Do not directly connect devices that exceed specified limits in technical specifications – observe startup current on inductive loads.

Electrical connections

Use only twisted pair copper conductors for input connections. The operating voltage must comply with the requirements for safety extra-low voltage (SELV) as per EN 60 730.

Use safety insulating transformers with double insulation. They must be designed for 100% ON-time. When using several transformers in one system the connection terminal 1 must be galvanically connected. The TCX2 is designed for operation by AC 24 V, max. 10 Amp, safety extra-low voltage that is short-circuit-proof. Supplying voltages above AC 24 V may damage or destroy the controller or any other connected devices.

Additionally, connections to voltages exceeding 42 V endanger personnel safety. Observe limits mentioned in the technical specifications. Local regulations must be observed at all times.

Bus connection

Wire type

An EIA-485 network shall use shielded, twisted-pair cable for data signaling with characteristic impedance between 100 and 130 ohms. Distributed capacitance between conductors shall be less than 100 pF per meter (30 pF per foot). Distributed capacitance between conductors and shield shall be less than 200 pF per meter (60 pF per foot). Foil or braided shields are acceptable.

Line termination

On last node on either end of bus only connect 120Ω termination resistor between (+) and (-).

Maximum length


The maximum recommended length per segment is 1200 meters (4000 feet) with AWG 18 (0.82 mm² conductor area) cable.

Shield connection

See Ashrae Standard 135 for detailed recommendation regarding how to connect the shield depending on type of nodes present in network.

Vector Controls bus modules are isolated devices.

Communication wiring



LED indicators

A status LED is located on the upper left side of the controller housing. During normal operation the LED blinks briefly once every 5 seconds. If there is an alarm or fault condition it will blink every second.

The Modbus slave features a green LED and a red LED for indication of traffic on the RS-485 bus. The green LED is lit when an incoming packet is received, and the red LED is lit when an outgoing packet is transmitted to the bus. At power-up, both LED blink twice simultaneously as a sign of the boot process being completed. A constantly lit LED serves as an indication of a fault condition in the reception or sending process.

Installation

See installation sheet no. 70-000599 (www.vectorcontrols.com).

Selection of actuators and sensors

Temperature sensors: Use Vector Controls NTC sensors to achieve maximum accuracy: SDB-Tn10-20 (duct), SRA-Tn10 (room), SDB-Tn10-20 + AMI-S10 as immersion sensor.

Actuators: Choose modulating actuators with an input signal type of 0-10 V DC or 4-20 mA (Min. and max. signal limitations may be set with parameters. 3-point actuators with constant running time are recommended.

Binary auxiliary devices (e.g. pumps, fans, on/off valves, humidifiers, etc.): Do not directly connect devices that exceed specified limits in technical specifications – observe startup current on inductive loads.


Electrical connections

Use only twisted pair copper conductors for input connections. The operating voltage must comply with the requirements for safety extra-low voltage (SELV) as per EN 60 730.

Use safety insulating transformers with double insulation. They must be designed for 100% ON-time. When using several transformers in one system the connection terminal 1 must be galvanically connected. The TCX2 is designed for operation by AC/DC 24 V, max. 10 Amp, safety extra-low voltage power supply that is short-circuit proof. Supplying voltages above AC/DC 24 V may damage or destroy the controller or any other connected devices.

Additionally, connections to voltages exceeding 42 V endanger personnel safety. Observe limits mentioned in the technical specifications. Local regulations must be observed at all times.

Display and Operation



Operation modes		Control symbols	
	Occupied: (Comfort) All control functions operating per set points.		Heating (reverse) active
	Unoccupied: (Standby, Economy) If enabled, alternative setpoints are used with the intention to reduce energy consumption.		Cooling (direct) active
OFF	OFF: (Energy Hold Off, EHO) Normal control functions are inactive, inputs are monitored for alarms.		Schedule set
			Manual override, delay on enable function
			Fan active

Idle display

The idle display is activated when no key has been pressed for 30 seconds.
The contents of the idle display are selectable through parameters UP08 to UP14.
Setting UP08 to OFF will disable idle display. Last active control loop or manual output will remain displayed.

Display of control loop

Active when changing set points. Large digits show input value. Small digits show set point. Horizontal bars top left show which loop is being displayed.

Override of secondary set point in cascade control

If cascade control is active (with VAV for example) the user can override the primary loop and manually select the set point of the secondary loop (the loop is then changed to constant air volume mode). This function is helpful for tuning the VAV system. This feature may be disabled by setting UP02 to OFF.

While the secondary loop is displayed change the set point with UP/DOWN. The hand symbol appears.
Change setpoint again to cancel cascade override. The hand symbol disappears.

Delay on enable function

During a pending delay the hand symbol will be shown. For example, when the condition to activate the controller with 1FU is met, but a start-up delay is specified. The controller will remain switched off and show the hand symbol until the delay expires.

Status LED

A status LED is located on the upper left side of the controller housing. During normal operation the LED blinks briefly once every 5 seconds. It will blink every second in case there is an alarm or fault condition.

Power Failure

- All parameters and set points are memorized and do not need to be re-entered.
- Upon return of power: Based on UP05 the controller will start in OFF, occupied or the same mode as before.
- Clock and time schedule settings are retained for 48 hours after being powered for at least 10 hours.

Error messages

Err1: Communication error
 Err2: Internal data corrupt. Replace product.
 Err3: Initial power up after firmware update or internal error. Re-start product. If error reappears, replace product.
 Err4: Configuration error. Parameter settings are conflicting. Verify control setup; make sure all assigned inputs are enabled and functioning.
 Err5: Parameter copy mode: Copy error. If external module is addressed, communication error with external product.
 Err6: Parameter copy mode: Check sum mismatch of eeprom data. Data in external eeprom corrupt.
 Err7: Lead/Lag function error. At least one assigned lead/lag module is not assigned or failed.

Clock operation

The controller contains a real time clock with battery back-up. Up to 12 schedules based on time and day of the week may be programmed (Pr01 through Pr12). Schedules may change controller operation mode (on, off, occupied, unoccupied), change fan state, position an output, or change a loop set point. A blinking clock indicates that the time has not been set or the unit was without power for longer than 48 hours. The time needs to be set to allow time schedules to operate. Summer / winter time changeover may be activated using user parameters.

Clock setup


Press OPTION > 2 sec. SEL and current time displayed Press OPTION < 2 sec. to change time, Minutes blink: UP/DOWN to change, OPTION to save, Hours blink: UP/DOWN to change, OPTION to save, DAY1 blinks: UP/DOWN to change, OPTION to save weekday Day of month blinks, UP/DOWN to change, OPTION to save Month blinks, UP/DOWN to change, OPTION to save Year blinks, UP/DOWN to change, OPTION to save Press ESC or POWER to return	SEL 00:00 DAY1 (Mon) 01.01. 2014
--	--

Enable/disable time schedules


Press OPTION > 2 sec. current time and SEL displayed Press UP: PRO and SEL displayed Press OPTION: Time schedule status displayed OFF or ON (🕒) Press OPTION to toggle OFF/ON	SEL PRO 	Pro OFF/ON
--	---	---------------

Creating weekly time schedules


Step 1: Select a switching time (Up to 12, Pr01–Pr12)

Press UP while PRO-ON displayed: Press UP or DOWN to SCROLL Pr01 through Pr12, Press OPTION to select desired schedule (e.g. Pr01), 00:00 blinks Press UP/DOWN to select Pr01 switching time from 00:00–23:45 Press OPTION to save switching time (bar appears indicating step 1 complete): DAY 1 blinks	08:00 Pr01	
---	---------------	---


Step 2: Apply selected switching time (Pr01) to DAY1 (Mon) – DAY 7 (Sun) or 365 days (Annual schedule)

While Pr01 is displayed and DAY1 is blinking: If 365 is shown, press DOWN key. After this DAY 1 will show. Press UP: Activate Pr01 switching time for DAY1 (triangle appears on 1), Press DOWN: Deactivate Pr01 switching time for DAY1 (triangle disappears) Press OPTION to save Pr01 DAY1 (2 nd bar indicates step 2 complete): Repeat for DAY2 – DAY7	DAY1 Pr01 ▼ 1 2 3 4 5 6 7	
--	------------------------------------	---


Step 3: For weekly schedules: Select action for switching time (Pr01+Days)

The selection of switching time and weekdays for this time schedule is now completed. Press POWER to come to desired action for Pro1. The following options appear in this order: no = switching time not active OP = operation mode (ON, OFF, OCCUPIED, UNOCCUPIED) LP = set point AO = Position of analog output (output must be in manual mode by parameter setting) FAN = Fan state (output must be in manual mode by parameter setting) do = Position binary output – digital, 3-point or PWM (output must be in manual mode by parameter setting). Hday = Annual time schedule. Press UP/DOWN to scroll through the possible events(3 rd bar indicates step 3 complete) Press Option to complete selection of event	LP Pr01	
--	------------	---

Step 4: Select ID (For example: LP01 or FAN2)

For all non-operation mode changes, it is required to select the output or control loop in this step. For example for setpoint LP1, LP2, etc. or for an output the number of the output that should be changed. Press UP/DOWN to select, OPTION to complete	LP01 Pr01	
---	---------------------	---


Step 5: Complete switching event

Choose operation mode, setpoint or position of output Characteristics of action (e.g. 0–100% for A1) appear (5 th bar indicates step 5 complete) Press UP/DOWN to select, OPTION to complete	25% Pr01	
---	--------------------	---


Creating annual time schedules

Holiday schedules have priority over operation mode schedules. While a holiday schedule is active, the controller will be in the OFF-mode. Other weekly schedules will still be active. It will still be possible to manually override the controller while in holiday mode.


Step 1: For annual schedules: Select holiday (Pr01 – Pr12)

Press UP while PRO-ON displayed: Press UP or DOWN to SCROLL Pr01 through Pr12, Press OPTION to select desired schedule (e.g. Pr01), The following options appear in this order when pressing UP: no = switching time not active OP = operation mode (ON, OFF, OCCUPIED, UNOCCUPIED) LP = set point AO = Position of analog output (output must be in manual mode by parameter setting) FAN = Fan state (output must be in manual mode by parameter setting) do = Position binary output – digital, 3-point or PWM (output must be in manual mode by parameter setting). Hday = Annual time schedule: Holiday Press UP/DOWN to scroll through the possible events (1 st bar indicates step 1 complete) Press Option to complete selection of event	Hday Pr01	
---	---------------------	---


Step 1: Select start month of holiday (For example: 1-12)

Select month 1 for January and 12 for December. Month is blinking. Press UP/DOWN to select, OPTION to complete	14.07 Pr01	
---	----------------------	---


Step 2: Select start day of holiday (1-31)

Select the day of month (1 – 31). Day is blinking. This is the first day of the holiday. Controller enters off mode at 00:00. Press UP/DOWN to select, OPTION to complete	14.07 Pr01	
---	----------------------	---


Step 4: Select last month of holiday (For example: 1-12)

Select month 1 for January and 12 for December. Month is blinking. Press UP/DOWN to select, OPTION to complete	28.07 Pr01	
---	----------------------	---

Step 5: Select last day of holiday and complete switching event

Select day of month (1-31). Day is blinking. This is the last day of the holiday. Controller enters weekly scheduled mode after 23:59. Press UP/DOWN to select, OPTION to complete	28.07 Pr01	
--	----------------------	---

Heat – Cool – Fan only – Auto selection

<p>Press OPTION > 2 sec. SEL and current time displayed</p> <p>Press UP/DOWN</p> <p>Until small digits display H-C:</p> <p>Press OPTION</p> <p>Currently active Heat or Cool optional with fan symbol or Auto are displayed:</p> <p>Press OPTION again to toggle Heating only, cooling only, fan only in heating mode or cooling mode or auto in the following order:</p> <p>Auto: heating and cooling change automatically based on demand. This must be setup with FU3.</p> <p>Heat: Heating only. The controller stays in heating mode and will not switch to cooling.</p> <p>Heat & Fan: The controller is in fan only mode. The fan will activate based on heating sequence.</p> <p>Cool: Cooling only. The controller stays in cooling mode and will not switch to heating.</p> <p>Cool & Fan: The controller is in fan only mode. The fan will activate based on cooling sequence.</p>	<p>H-C</p> <p>SEL</p> 
--	--

Display of in- and output states


Step 1: Select type or in- or output

<p>Press OPTION > 2 sec. SEL and current time displayed</p> <p>Press UP/DOWN</p> <p>Until small digits display SEL, Large digits show:</p> <p>UI = universal inputs</p> <p>AO = Analog outputs</p> <p>FAN = Fan outputs</p> <p>do = Binary, 3-point or PWM outputs</p> <p>Press OPTION to display state of In- or Output</p>	<p>UI</p> <p>SEL</p>
---	-----------------------------

Step 2: Select number of in- or output

<p>Press UP/DOWN to step through the number of available in- or outputs</p> <p>Large digits show in-output type & number, Small digits show value</p>	<p>UI 01</p> <p>25%</p>
---	--------------------------------

Step 3: Display total run time for binary outputs

<p>While in binary output mode,</p> <p>Press OPTION key to display the total number of hours the binary output has been ON.</p> <p>Large digits show in-output type & number, Small digits show running time in hours.</p> <p>If the running time is larger than 9999 hours, 10000 hours are shown as level on the vertical bar.</p> <p>The example on the right equals 50345h running time.</p> <p>(Maximum runtime is 65535h = 7.5 years)</p>	<p>do 01</p> <p>345h</p> 
---	--

User and display parameters (Password 009)

Parameter	Description	Range	Default
UP 00	Enable access to operation modes	ON/OFF	ON
UP 01	Enable access to set points	ON/OFF	ON
UP 02	Enable manual control in cascade and for fan speeds	ON/OFF	ON
UP 03	Enable change of heating/cooling mode	ON/OFF	ON
UP 04	Enable access to time programs:	ON/OFF	ON
UP 05	State after power failure: 0= off, 1= on, 2= state before power failure	0, 1, 2	2
UP 06	Enable unoccupied Mode: Shift the setpoint to a lower temperature in winter or higher temperature in summer in order to save energy. Unoccupied mode may be activated through the POWER button, or with the external input (typically for key card switches, occupancy sensors in combination with door contacts for hotels or meeting rooms.)	ON/OFF	OFF
UP 07	Celsius or Fahrenheit: ON= Fahrenheit, OFF= Celsius	ON/OFF	OFF (Celsius)
UP 08	Show idle display while no key is pressed	ON/OFF	ON
UP 09	Select type of content for large digits (00= OFF): 00 = OFF 01 = Input 02 = Control loop setpoint	0-6	1
	03 = Analog output 04 = Fan 05 = Binary output 06 = Clock		
UP 10	Select content source for large digits (0= OFF):	0-12	1
	Input: 1 = UI1 2 = UI2 3 = UI3 4 = UI4 5 = UI5 6 = UI6 7 = UI7 8 = UI8 9 = VI1 10 = VI2 11 = VI3 12 = VI4 Set point: 1 = LP1 2 = LP2 3 = LP3 4 = LP4 Analog output: 1 = AO1 2 = AO2 3 = AO3 Fan: 1 = Fan 1 2 = Fan 2 Binary output: 1 = DO1 2 = DO2 3 = DO3 4 = DO4 5 = DO5 6 = DO6		
UP 11	Select type of content for small digits (same options as UP09)	0-6	2
UP 12	Select content source for small digits (same options as UP10)	0-10	1
UP 13	Select type of content for vertical bar display (same options as UP09)	0-6	3
UP 14	Select content source for vertical bar (same options as UP10)	0-10	1
UP 15	OFF = Do not show heating & cooling state, ON = Display heating & cooling state	ON/OFF	ON
UP 16	OFF = Alarms display only while active, ON = Alarms display until confirmed,	ON/OFF	ON
UP 17	Clock display type (12/24): OFF= 24-hr ON= 12-hr (AM/PM)	ON/OFF	OFF(24hr)
UP 18	Reset timer for manual override in time schedule mode. 0 = Reset of override mode is not active. Time schedules overridden manually will be switched back to scheduled mode at next switching event. 1...255 = Delay for the controller to go back to the scheduled OFF or unoccupied operation mode if the operation mode is changed manually to occupied.	0-255 Min	60(Min)
UP 19	Constant backlight for display: OFF = The backlight is only on when a key has been pressed ON = The backlight is constantly on	ON/OFF	OFF
UP 20	Do not show input value in loop display OFF = Input value is shown ON = Only setpoint is shown. Input value is not visible in loop display	ON/OFF	OFF
UP 21	Enable daylight savings mode. If enabled, internal real time clock will be advanced by one hour in summer and delayed one hour in winter	ON/OFF	OFF
UP 22	TCX2 is in no-reply-mode for OPA2-VC communication OFF = TCX2 is in normal mode for communication with OPA2-VC ON = TCX2 is in no-reply-mode for communication with OPA2-VC No-reply-mode: This mode allows connecting one operation terminal to multiple controllers. One controller must be in normal operation mode and all the others must be set to no-reply-mode. The controllers set to no-reply-mode will follow each command issued by the operation terminal. They will not send responses and their alarm conditions are not monitored by the operation terminal. Setting a controller with only one operation terminal to no-reply-mode will result in communication error on the operation terminal. In this case parameter UP22 can still be changed to 0 through the operation terminal.	ON/OFF	OFF
UP 23	Wink function: the LED on top lights up constantly if ON OFF = LED has normal function ON = LED is constantly active	ON/OFF	OFF
UP 24	Summer / winter mode. Used for control loops, to select the corresponding setpoint limits. Set in xL28 OFF = Summer mode (cooling), ON = Winter mode (heating)	ON/OFF	OFF

Setting parameters to configure the controller

TCX2 is an intelligent controller with the flexibility to fit a wide range of applications. The control operation is defined by parameters set using the standard operation terminal. There are two levels:

1. **User/display parameters (password 0009)**
2. **Control parameters (password 0241)**

Recommended set-up procedure:

1. **Set jumpers on the back of the controller for inputs and outputs**
2. **Connect power supply and inputs**
3. **Make sure Celsius – Fahrenheit settings are correct (UP07)**
4. **Program input parameters**
5. **Program control parameters**
6. **Program output parameters**
7. **Program auxiliary functions and user settings**
8. **Test function of unit**
9. **Switch off power**
10. **Connect outputs**
11. **Reconnect power**
12. **Test control loop**

Parameters are grouped according to modules:

Module	Description	PW
UP	User and display parameters	009
LP	Control loops Lp1 to Lp4	241
UI	Input configuration: 1U to 8U,	
AL	Alarm configuration: 1AL to 8AL	
FU	Special functions Fu1 to Fu5	
AO	Analog output configuration, AO1 to AO3	
FAN	Fan output configuration FAN1 to FAN2	
DO	Binary output configuration, do1 to do6	
Co	Communication setup (refer to separate communication brochure)	
COPY	copy mode to copy full parameter sets between run, default and external memory with up to 4 saving locations (AEC-PM1)	

How to change parameters

1. Press UP/DOWN buttons simultaneously for three seconds. The display will show firmware version and revision number. Press the OPTION button to start login.
2. CODE is shown in small display. Select 241 or the number provided by your supplier using the UP or DOWN button. These are the default access numbers, your supplier may have changed those numbers or blocked access to the parameters completely. Parameters should only be changed by authorized personnel.
3. Press OPTION after selecting the correct code. The user/display parameters are displayed immediately.
4. Once logged in with 241 control modules are displayed (UI, AL, LP, AO, FAN, DO, CO etc.) – select with UP/DOWN and open with OPTION. Then select the ID with UP/DOWN keys: 1U, 2U, 3U etc., open with OPTION. As soon as the module is open its parameters are displayed.
5. Select the parameters with the UP/DOWN buttons. Change a parameter by pressing the OPTION button. Three arrows are displayed to indicate that the parameter may be modified. Use UP/DOWN buttons to adjust the value.
6. After you are done, press OPTION to save the new value and return to the selection level (arrows disappear when selection is saved). Pressing left hand POWER button without pressing OPTION will discard the value and return without saving.
7. Press POWER to leave parameter selection and return to control module selection.
8. Press the POWER to leave the menu. The unit will return to normal operation, if no button is pressed for more than 5 minutes.

How to select active alarms on outputs and special functions

1. Select the parameter as described above
2. Press OPTION to start selecting alarms. AL 1 is now shown in the large digits.
3. Press UP to select the alarm 1, press DOWN to deselect the alarm 1. A selected alarm is visible by a dark triangle on the bottom line of the LCD. The output or function will activate if the corresponding alarm is triggered.
4. Press OPTION to step to alarm 2. Repeatedly press OPTION key to step through all available alarms and select or deselect them by pressing UP or DOWN.
5. Press POWER to leave the alarm selection routine and return to the parameter selection level.

Copying and restoring the entire parameter set

It is possible to backup and refresh the entire parameter set to a second onboard memory (default memory) or a plug-in memory. This simplifies substantially the programming of multiple controllers with identical parameter sets.

Removable plug-in memory AEC-PM1

The plug-in memory is an accessory that can be plugged in on the right side of the TCX2. Once connected, the power LED on the AEC-PM1 lights up. The memory can hold up to 4 individual parameter sets. It is easy for a site engineer to update a variety of standard installations or for an OEM to program his standard setup based on application.

Auto-load

While copying a parameter set to eeprom, the user may choose the auto-load feature. With this feature set, the parameters load automatically when powering up the controller. It is thus possible for a non-technical person to perform a parameter update by simply powering up the controller with the AEC-PM1 plugged in.

Procedure to copy parameter sets

1. Login to engineering parameters as described above.
2. Press UP or DOWN until COPY is selected
3. Press the OPTION key. Select copy source: These are the options:

0. CLR	⇒	The copy destination will be erased
1. RUN	⇒	Run time memory
2. DFLT	⇒	Default: On board backup memory
3. EEP1	⇒	External memory folder 1 on AEC-PM1
4. EEP2	⇒	External memory folder 2 on AEC-PM1
5. EEP3	⇒	External memory folder 3 on AEC-PM1
6. EEP4	⇒	External memory folder 4 on AEC-PM1
4. Press OPTION key. Now select copy destination: These are the options:

1. RUN	⇒	Run time memory
2. DFLT	⇒	Default: On board backup memory
3. EEP1	⇒	External memory folder 1 on AEC-PM1
4. EEP2	⇒	External memory folder 2 on AEC-PM1
5. EEP3	⇒	External memory folder 3 on AEC-PM1
6. EEP4	⇒	External memory folder 4 on AEC-PM1
5. Press OPTION key. Your selection is shown on the large digits: source ID to target ID. For example run time memory to eep1 is shown as 1to3. After confirming the selection, choose YES or AUTO to start the copy process. Select NO to abort. AUTO is only available if the target is the external plug in. By selecting AUTO: The parameters will load automatically when the controller is powered up while the AEC-PM1 is plugged in. If one plug-in has several parameter folders with the AUTO flag set the one with the smallest index will be loaded.

For products with a communication plug-in. Selecting CO15 = 01 will write back an increased address to the AEC-PM1 after a successful copy. This way it is easier to configure large projects.

6. Press the OPTION key to conclude the selection. The Data LED on the AEC-PM1 plug-in blinks to indicate data communication in case it is copied to or from. PEND is shown while the copy process takes place. There are several possibilities for the result:
 - Good: The copy process was successful
 - Fail: Err5, Communication problem. The plug in module is either damaged or missing
 - Fail: Err6, Checksum mismatch. The checksum of the source data was incorrect. Data corruption. This may happen if the plug-in has not been written to before or data corruption took place.

Exchanging parameter sets with a computer

Through a USB/RS485 converter it is possible to read and write parameter sets to a computer by the use of a free program called EasySet. The EasySet tool may be downloaded from the vectorcontrols.com website.

To exchange parameter sets, install the EasySet™ configurator program and plug in the USB/RS485 converter to your computer. Connect the RS485 converter to the OP3 (+) and OP4 (-) terminal of the TCX2 using a twisted pair wire. If an OPA2-VC is connected, you must first unplug it. In order to use EasySet, select the port of your USB converter first. Parameter sets may now be read out from the TCX2 to the PC and written back to the TCX2. This makes it possible to keep a parameter library on computer, exchange parameter sets through emails or keep a log file of all the projects completed.

Input & alarm/interlock configuration

Overview

There are two types of inputs for the TCX2: Universal and Virtual Inputs.

Universal inputs are physical inputs that measure a signal connected to them.

Virtual inputs are inputs provided by operation terminals, communication plug-ins or special input functions.

On this TCX2 there are 8 universal and 4 virtual inputs.

Universal inputs (analog, binary or passive)

Parameter	Description	Range	Default
01 u0	For universal inputs: 1U to 8U: Signal type (0= not active): 1= 0-10V or 0-20mA 2= 2-10V or 4-20mA 3= NTC 4 = open contact direct (contact open = 100%, closed = 0%) 5 = open contact reversed (contact open = 0%, closed = 100%) 6 = potentiometer input, assign to setpoint selection of control loop 7 = light control mode: toggle and dimmer switch 8 = pulse counting input.	0-8	1
01 u1	Display minimum value. See note below about display resolution. For potentiometer input: lower range limit of potentiometer in 100 Ohm steps Only if xxu0 = 1, 2 or 6: if minimum value is higher than maximum value, the input signal is reversed. 0% input = 100% signal, 100% input = 0% signal	-50-205	0
01 u2	Display maximum value. See note below about display resolution. For potentiometer input: Upper range limit of potentiometer in 100 Ohm steps Only if xxu0 = 1, 2 or 6: if minimum value is higher than maximum value, the input signal is reversed. 0% input = 100% signal, 100% input = 0% signal	-50-205	100
01 u3	Range of universal inputs (For analog inputs only: 1u0 = 1,2) 0 = x1 3 = square root 1 = x10 4 = square root x 10 2 = x100 5 = square root x 100	0 - 5	0
01 u4	Analog input unit: 0= no unit, 1= %, 2= °C /°F, 3= Pa	0-3	1
01 u5	When 01u0 = 1-5: Select number of samples taken for low pass filter: Filtering prevents unwanted fluctuation of sensor signals. The controller measures signal inputs every second and calculates the input signal based on a number of measured values and a digital low pass filter. Take into account that signal reaction delays as the number of samples taken for the filter increases. Note: changing this value will as well change 01u8	0-100	3
01 u6	Sensor calibration	Per input range	0.0
01 u7	Calculate mathematical function over multiple inputs (0=not active): 1= average, 2= minimum, 3= maximum, 4= differential UI(n) - UI(n-1)	0-4	0
01 u8	When 01u0 = 7 (light switch), select auto switch off time. Set to 0, if output should not automatically switch off. Note: Shared value: changing this value will as well change 01u5	00:00s...15:10h MM:SS...HH:MM	00:15 MM:SS

- ➔ Set jumpers on the back of the controller: 0-10VDC (default), 0-20mA, or RT/DI (passive temperature or binary)
- ➔ Match sensor range to input display range. With a differential pressure transmitter having 0-200 Pa measuring range set 01U1 display minimum to 0 and 01U2 display maximum to 200. The allowable range value of -50-205 may be adjusted with multipliers in 01U3. The largest displayable values are -990-9999.
- ➔ Passive temperature input is NTC 10k@25°C (77°F). Specified accuracy can only be guaranteed using Vector Controls Sxx-Tn10 sensors. Range values described above also apply to temperature inputs.
- ➔ **Display resolution (01u1 and 01u2)**
Limiting the display range increases set point resolution. A range <25 provides set point steps of 0.1°C (0.2°F). A range <125 provides set point steps of 0.5 °C (1.0 °F). Larger ranges increase by 1.0 step.
Square root input range (0xu3) has no influence. Note: Fahrenheit and differential step widths are doubled.
- ➔ **Open contact as input type (01u0 = 4 or 5):** For an open contact input set the jumper to RT/DI and parameter 01u0 to open contact (4 or 5). If set to 4 (open contact direct), an open contact reads as a high value (100%), a closed contact as a low value (0%). If set to 5 (open contact reversed), an open contact reads as low value (0%) and a closed contact as high value (100%). Note: sensor calibration does not work for binary inputs.

- ➔ **Potentiometer input (01u0 = 6).** A potentiometer may be connected to a passive input to control the setpoint of a control loop. With the input display minimum and maximum values the range of the potentiometer can be defined in 100 ohms steps. For example setting the 1u01 to 50 and 1u02 to 120 represents a potentiometer from 5k to 12k Ohm. The resistance is measured and calculated into a 0-100% value. Based on the potentiometer input, the setpoint will now be moved between the upper and lower setpoint limits of the control loop. There are other uses for the potentiometer input. For example, the controller can be enabled and disabled remotely with a potentiometer using an input in potentiometer mode assigned to the Auxiliary Function Enable/Disable (1FU). Or use Alarm/Interlocks assigned to the potentiometer input to activate or deactivate outputs. With the potentiometer fully on, for example, another interlock could activate a boost mode. The potentiometer could then read OFF (65°F) to Full (85°F). Add one more wire connected to a 10k-2 resistor and measure the room temperature as well. Thus with 3 wires in total (potentiometer, common, room temperature) a well-functioning low-cost operation terminal may be realized.
- ➔ **Light control mode: toggle and dimmer switch (01u0 = 7):** Manage lighting with TCX2 and special functions such as alarms, time schedules and automatic occupied/unoccupied mode switch can be used for occupant convenience and to reduce lighting costs. With this feature building light is controlled by using push-button switches in the room connected to passive inputs on TCX2. A passive input is assigned directly to an output connected to a relay for the light. This is achieved by setting xd01 to 9. An analog output is assigned directly to an input by assigning xA00 to 7. Use binary outputs for on/off lights or add an analog output for dimming. Pressing the push-button switch for less than 2 seconds will toggle the binary output. For dimming, pressing the push-button switch for longer than 2 seconds will change the input value by 10% per second from 0% to 100% and again back to 0%.

Pulse counting mode

01 u0	For universal inputs: 1U to 8U: Signal type (0= not active): 1= 0-10V or 0-20mA 2= 2-10V or 4-20mA 3= NTC 4 = open contact direct (contact open = 100%, closed = 0%) 5 = open contact reversed (contact open = 0%, closed = 100%) 6 = potentiometer input, assign to set point selection of control loop 7 = light control mode: toggle and dimmer switch 8 = pulse counting input.	0-8	8
01 u1	Not used	-50-205	0
01 u2	Value to be added with each pulse. For single pulse counting set to 1. This value will only be used if u7 = 0.	-50-205	1
01 u3	Range of universal inputs 0 = x1 1 = x10	0 - 1	0
01 u4	Analog input unit: 0= no unit, 1= %, 2= °C /°F, 3= Pa	0-3	1
01 u5	Save value to eeprom, only after every n sample will the data be saved to eeprom. The eeprom allows for 100'000 guaranteed saves. In order to guarantee reliable operation this multiplier should be set to prevent premature aging of the controller. 0 = 1 every sample is saved. 1 = 10 after 10 samples data is saved to the eeprom 2 = 100 after 100 samples data is saved to eeprom 3 = 1000 after 1000 samples data is saved to eeprom	0..3	0
01 u6	Reset counter: any value other than 0 will reset the counter. Once this value is set to 1 and saved, the counter will be reset to 0 immediately.	0...255	0
01 u7	Select Input whose value is used to be added with each pulse.	0-12	0

- ➔ **Pulse counting mode: (01u0 = 8):** With this feature it is possible to count pulses from a water or energy meter and summarize a constant value or the result of an input.
- ➔ For frequent pulses the summary option of u5 is recommended. This will save only every 10th or 100th pulse to the eeprom and keep the values until then in RAM. This bears the risk that those values will not be remembered after a power failure.
- ➔ With u07 the value of two inputs may be used in conjunction with the Pulse Counting Input to calculate energy consumption. For example, apply the Mathematical Function-Differential to supply and return water temperature for a heating system. The calculated value of a series of inputs is shown on the input with the higher number. When UI1 supply water temperature and UI2 return water temperature both have Mathematical Function-Differential parameter selected the difference between supply and return temperature will be shown on UI2. When the Pulse Counting input parameter u07 is set to 2, the difference between supply and return temperature is added to the total at each pulse of the flow meter. This total then represents energy consumption.

Virtual input configuration

01 u0	For virtual inputs: 9U to 12U: Select signal source 1 = Operation terminal OPA2-VC, OPU2-2TH-VC, etc. 2 = Bus module: AEX-MOD (Modbus), AEX-BAC (BACnet) 3 = Special input functions (configuration, see next page)	0-3	0
01 u1	Display minimum value	-50-205	0
01 u2	Display maximum value	-50-205	100
01 u3	Range of universal inputs (For analog inputs only) 0 = x1 1 = x10 2 = x100	0 - 2	0
01 u4	Analog input unit of measure: 0= no unit, 1= %, 2= °C /°F, 3 = Pa	0-3	2
01 u5	Not used for virtual inputs. Do not change	0-100	12
01 u6	Sensor calibration	Per input range	0.0
01 u7	Calculate mathematical function over multiple inputs (0=not active): 1= average, 2= minimum, 3= maximum, 4= differential UI(n) - UI(n-1)	0-4	0
01 u8	Select timeout: If the value is not updated within the specified time period, the input will be disabled. If the input is assigned to an active control loop or a function configuration error Err4 is shown.	00:00s...15:10h MM:SS...HH:MM	01:00 MM:SS

- ➔ Virtual inputs may originate from a remote operation terminal such as the OPA2-VC or from a bus master if a communication module such as the AEX-MOD for MODBUS or AEX-BAC for BACnet is present.
- ➔ The remote input has a selectable timeout. If the value is not updated within this timeout, the input will be disabled and the configuration error Err4 is shown. Rewriting the input value will re-enable the input but will not clear Err4. Err4 can only be cleared by acknowledgement through the right key. Setting the timeout to 0 disables its function. For control functions, the timeout should not be disabled. While no additional setup is required on the OPA2, the bus master needs to write its value to the correct address for the input within the timeout period. Details are described in the documentation of the communication module.
- ➔ Inputs of OPA2-VC:
The OPA2-VC has one temperature input. This input is assigned to the first virtual input. For the TCX2-40863 this would be input 9. To use the temperature input of OPA2-VC, set 09u0 = 1.
- ➔ Inputs of OPT1-2TH-VC, OPA2-2TH-VC, OPU2-2TH-VC or OPT1-HTNV-VC:
The OPA2-2TH-VC and OPT1-2TH-VC have a temperature input, a humidity input and 2 binary inputs. These inputs are assigned to following virtual inputs:
 1. VI1 = UI9 = temperature input
 2. VI2 = UI10 = humidity input
 3. VI3 = UI11 = passive input 1
 4. VI4 = UI12 = passive input 2, For OPT1-HTNV-VC input 2 0...10 VDC

Mathematical functions on universal and inputs from bus terminals and plug-ins.

- ➔ Square root calculation on input values: The input signal maybe subjected to the square root function prior to calculating the display values. The square root is calculated from the input signal and the result is again conditioned to 10bit resolution. The square root function is useful when airflow needs to be calculated from differential pressure, as in VAV systems for example.

The following is true for the mathematical function of each physical input or inputs from operation terminals and plug-ins. The special input functions of the virtual inputs use a different logic.

- ➔ Calculate mathematical functions over multiple inputs for loop control or display with xxU7. In order to calculate average, minimum or maximum between several inputs, make sure all the inputs are of identical type and range and then activate the same function on xxU7 on all the selected inputs. The largest input of the group selected will carry the calculated value. For example: When average is activated on 02U7 and 01U7 = 1, the average is carried on universal input 2.

UI2 may now be used as input for control loops and it will show the average value of UI1 and UI2 combined. It is possible to use different functions on different inputs. For example: minimum of UI1 and UI3 and maximum of UI2 and UI4.
- ➔ The differential function may only be calculated on subsequent inputs. Such as UI2-UI1. The function must only be activated on the minuend (a number from which another number is subtracted) - UI2 in this example. The displayed value of the minuend will change into the difference: UI2 in - UI1 = UI2 out. It is possible to have multiple differentials on one controller. It is not possible to reverse the subtraction: UI1-UI2.

Special function input configuration

09 u0	For virtual inputs: 9U to 12U: Select signal source 1 = Operation terminal OPA2-VC, OPU2-2TH-VC, etc. 2 = Bus module: AEX-MOD (Modbus), AEX-BAC (BACnet) 3 = Special input function	0-3	3
09 u1	Display minimum value	-50-205	0
09 u2	Display maximum value	-50-205	100
09 u3	Range of universal inputs (For analog inputs only) 0 = x1 1 = x10 2 = x100	0 - 2	0
09 u4	Analog input unit of measure: 0= no unit, 1= %, 2= °C /°F, 3 = Pa	0-3	2
09 u5	Calculate mathematical or physical functions over multiple inputs: 0 = off 1 = average (input 1 + input 2)/2 2 = minimum 3 = maximum 4 = difference (input 1 - input 2) 5 = addition (input 1 + input 2) 6 = dew point (input 1: temperature, input 2: relative humidity) 7 = enthalpy of humid air (input 1: temperature, input 2: relative humidity)	0-7	0
09 u6	Select type of function input 1 0 = universal and virtual inputs 1 = heating sequence of control loops 2 = cooling sequence of control loops 3 = heating & cooling sequence of control loops 4 = analog outputs 5 = digital outputs 6 = fan outputs	0...6	0
09 u7	Select ID of function input 1	0...12	0
09 u8	Select type of function input 2	0...6	0
09 u9	Select ID of function input 2	0...12	0

- ➔ A virtual input configured as special input function calculates its signal based on selected inputs and functions
- ➔ An input to a special input function can be a physical input, a virtual input, a control sequences or an output.
- ➔ It is possible to compare sequences with physical inputs or outputs. Choose function with parameter 09u5 and item 1 with 09u6/09u7 and item 2 with 09u8/09u9.
- ➔ All sequences and outputs are calculated as 0...100%.
- ➔ The inputs do not have to use same display range as in the mathematical functions of each input. The function calculates absolute values. The only exception to this rule is multipliers. All inputs must use the same multipliers; those multipliers should match as well the setting of the special input function xxu3.
- ➔ For enthalpy and dew point function the temperature input needs to be on input 1 and humidity on input 2. Permissible input signal range is temperature from 0.1 to 80°C (32.5 to 176 °F) and from 0 to 100% relative humidity. If signal is outside of this range, the minimum or maximum values will be used instead.

Alarm function

→ Number of available alarms.

8 alarms are available. The highest priority alarm is alarm 1, the lowest one is alarm 8.

→ The following alarm functions are available.

They are described in greater detail in the following pages:

- High or low limit alarm configuration
- Alarm based on maximum set point deviation of control loop
- Maintenance alarm based on run time counters
- Feedback or output alarms
- Alarms based on control loop sequence
- Timeout or cycle mode for outputs

→ Operating the interlock in off mode:

Normally an interlock should not operate while the controller is in OFF mode. However, there are exceptions. To activate an interlock in OFF mode, set its AL4 value to ON. Make sure AL4 is set to OFF if it should not activate an output in OFF mode.

→ Alarm automatic reset or acknowledge only (AL4).

Certain alarms should automatically reset once the condition is removed, but still keep the end user informed that the alarm condition occurred: A typical example is a frost alarm. If the temperature drops too low, the heat should come on and it should stop again once the frost protection reset temperature is reached.

If an alarm indicates a failure of system equipment that would endanger the operation of a device, the alarm should not automatically reset. For example, when a fan fails to come on or a pump does not operate. In this case the alarm situation needs to be resolved before restarting the outputs.

By setting AL3 to ON the engineer determines that the alarm must be reset manually before normal operation can continue.

→ Alarm delay, alarm limit and alarm reset:

For the above alarms, an activation delay, a limit and a reset (where applicable) may be defined. The reset determines when the alarm condition will return to normal. It is used with input limit alarms, in frost protection for example. The frost protection alarm is activated once the temperature drops below 5°C (41°F), the alarm reset is set to 5K. The room is now heated until the temperature reaches 5°C (41°F) + 5K = 10°C (50°F). Once this temperature is reached the alarm will switch off, it will remain blinking until acknowledged.

→ Alarm Settings on Outputs

The position of an output in the event of an alarm may be defined for each output and each alarm individually. The output can be switched on (100%) or off (0%).

Additionally, analog outputs may now as well be set to a predefined value. To achieve this, the same alarm needs to be selected in the ON and OFF register. An additional parameter is provided to choose the desired alarm level.

Priority for output control

1. Alarm level low
2. Alarm level high
3. Operation mode OFF
4. Control function

→ The alarm takes precedence over operating state and control signal. For interlocks, its operation during OFF mode is defined through parameter AL4.

→ Two parameters define the behavior of the output based on an alarm: One parameter defines which alarm deactivates the output (0%); the other parameter defines which alarm activates the output to 100%. Each alarm can be individually selected. Multiple alarms can be assigned to one output. Should an alarm be active simultaneously in the parameter to activate and another one to deactivate the output, the one to de-activate has precedence.

High or low limit alarm configuration

1AL 0	Select alarm type: 0 = Alarm is not active 1 = Input high or low limit (Select input in AL 2) 2 = Max. set point deviation of control loop (select loop in AL 1) 3 = Maintenance alarm from run time counters (select counter in AL 1) 4 = Feedback or output alarm for fan, supervise fan state (Select fan in AL 1) 5 = Feedback or output alarm for binary output (select output in AL 1) 6 = Feedback or output alarm for analog output (select output in AL 1) 7 = Level alarm or interlock for PI-sequence of control loop (select output in AL 1) 8 = Timeout or cycle mode for outputs. (select type in AL 2 and ID in AL 1)	0...8	0
1AL 1	Not used	0...8	0
1AL 2	Select supervised input if 1AL0 = 1 0 = not active, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0...12	0
1AL 3	Alarm or interlock mode OFF = Alarm mode active: Icon and the words ALA# on the small digits indicating active alarm will appear on display, reset option in 1AL4 applies. ON = Interlock mode: Outputs revert to normal operation when alarm condition is no longer present, Icon and text indicating active alarm will not appear.	OFF, ON	OFF (Alarm)
1AL 4	Automatic reset or acknowledge to reset (only if AL3 = OFF) OFF = Alarm condition resets automatically. After alarm condition is no longer present, outputs will revert to normal operation, but alarm Icon will continue to blink on display until acknowledged with Option key. ON = Alarm condition must be reset manually. After alarm condition is no longer present, outputs will remain in alarm setting, and Icon will continue to show on display, until acknowledged with Option key. Note: All alarms operate as well if the controller is in OFF mode.	OFF, ON	OFF (Automatic reset)
	Select if interlock is active in OFF mode (only if AL3 = ON) OFF = Interlock is not active while controller is in off mode or disabled ON = Interlock is active independent of controller state		
1AL 5	Delay until alarm is active	00:00s...15:10h MM:SS...HH:MM	00:00 MM:SS
1AL 6	Type of alarm (applies only if AL0 = 1, 7) OFF = Low limit alarm ON = High limit alarm	OFF, ON	OFF
1AL 7	Alarm limit for input based alarms (applies only if AL0 = 1, 4 to 6 in feedback mode) Note: shared value. Changing this input will as well change 1AL9	Per input range	10%
1AL 8	Hysteresis for alarm setback for input based alarms (applies only if AL0 = 1) Note: shared value. Changing this input will as well change 1ALA	Per input range	5%
1AL 9	Not used	0...100%	8%
1AL A	Not used	0...100%	4%

Alarm based on maximum set point deviation of control loop

1AL 0	Select alarm type: 0 = Alarm is not active 1 = Input high or low limit (Select input in AL 2) 2 = Max. set point deviation of control loop (select loop in AL 1) 3 = Maintenance alarm from run time counters (select counter in AL 1) 4 = Feedback or output alarm for fan, supervise fan state (Select fan in AL 1) 5 = Feedback or output alarm for binary output (select output in AL 1) 6 = Feedback or output alarm for analog output (select output in AL 1) 7 = Level alarm or interlock for PI-sequence of control loop (select output in AL 1) 8 = Timeout or cycle mode for outputs. (select type in AL 2 and ID in AL 1)	0...8	2
1AL 1	Select control loop if 1AL 0 = 2,7, Note: max deviation limit is defined in control loop parameters 0 = all active control loops (not valid if 1AL0 = 7) 1 = loop 1 to 4 = loop 4	0...8	1
1AL 2	Not used	0...12	0
1AL 3	Alarm or interlock mode OFF = Alarm mode active: Icon and the words ALA# on the small digits indicating active alarm will appear on display, reset option in 1AL4 applies. ON = Interlock mode: Outputs revert to normal operation when alarm condition is no longer present, Icon and text indicating active alarm will not appear.	OFF, ON	OFF (Alarm)
1AL 4	Automatic reset or acknowledge to reset (only if AL3 = OFF) OFF = Alarm condition resets automatically. After alarm condition is no longer present, outputs will revert to normal operation, but alarm Icon will continue to blink on display until acknowledged with Option key. ON = Alarm condition must be reset manually. After alarm condition is no longer present, outputs will remain in alarm setting, and Icon will continue to blink on display, until acknowledged with Option key. Note: All alarms operate as well if the controller is in OFF mode. Select if interlock is active in OFF mode (only if AL3 = ON) OFF = Interlock is not active while controller is in off mode or disabled ON = Interlock is active independent of controller state	OFF, ON	OFF (Automatic reset)
1AL 5	Delay until alarm is active	00:00s...15:10h MM:SS...HH:MM	00:00 MM:SS
1AL 6	Not used	OFF, ON	OFF
1AL 7	Not used	Per input range	10%
1AL 8	Not used	Per input range	5%
1AL 9	Not used	0...100%	8%
1AL A	Not used	0...100%	4%

*See maximum control loop set point deviation parameter xL26

Maintenance alarm based on run time counters*

1AL 0	Select alarm type: 0 = Alarm is not active 1 = Input high or low limit (Select input in AL 2) 2 = Max. set point deviation of control loop (select loop in AL 1) 3 = Maintenance alarm from run time counters (select counter in AL 1) 4 = Feedback or output alarm for fan, supervise fan state (Select fan in AL 1) 5 = Feedback or output alarm for binary output (select output in AL 1) 6 = Feedback or output alarm for analog output (select output in AL 1) 7 = Level alarm or interlock for PI-sequence of control loop (select output in AL 1) 8 = Timeout or cycle mode for outputs. (select type in AL 2 and ID in AL 1)	0...8	3
1AL 1	Select run time counter of which binary output if AL 0 = 3, 0 = all binary outputs 1 = Digital output 1 to 6 = Digital output 6	0...8	0
1AL 2	Not used	0...12	0
1AL 3	Alarm or interlock mode OFF = Alarm mode active: Icon and the words ALA# on the small digits indicating active alarm will appear on display, reset option in 1AL4 applies. ON = Interlock mode: Outputs revert to normal operation when alarm condition is no longer present, Icon and text indicating active alarm will not appear.	OFF, ON	OFF (Alarm)
1AL 4	Automatic reset or acknowledge to reset (only if AL3 = OFF) OFF = Alarm condition resets automatically. After alarm condition is no longer present, outputs will revert to normal operation, but alarm Icon will continue to blink on display until acknowledged with Option key. ON = Alarm condition must be reset manually. After alarm condition is no longer present, outputs will remain in alarm setting, and Icon will continue to blink on display, until acknowledged with Option key. Note: All alarms operate as well if the controller is in OFF mode. Select if interlock is active in OFF mode (only if AL3 = ON) OFF = Interlock is not active while controller is in off mode or disabled ON = Interlock is active independent of controller state	OFF, ON	OFF (Automatic reset)
1AL 5	Delay until alarm is active	00:00s...15:10h MM:SS...HH:MM	00:00 MM:SS
1AL 6	Not used	OFF, ON	OFF
1AL 7	Not used	Per input range	10%
1AL 8	Not used	Per input range	5%
1AL 9	Not used	0...100%	8%
1AL A	Not used	0...100%	4%

* See digital output parameters xd09 and xd10

Feedback or output alarms

1AL 0	Select alarm type: 0 = Alarm is not active 1 = Input high or low limit (Select input in AL 2) 2 = Max. set point deviation of control loop (select loop in AL 1) 3 = Maintenance alarm from run time counters (select counter in AL 1) 4 = Feedback or output alarm for fan, supervise fan state (Select fan in AL 1) 5 = Feedback or output alarm for binary output (select output in AL 1) 6 = Feedback or output alarm for analog output (select output in AL 1) 7 = Level alarm or interlock for PI-sequence of control loop (select output in AL 1) 8 = Timeout or cycle mode for outputs. (select type in AL 2 and ID in AL 1)	0...8	4 - 6
1AL 1	Select fan, binary or analog output if 1AL 0 = 4, 5, 6, 8 0 = Interlock or alarm not active 1..x = selected output	0...8	1
1AL 2	Select supervised input or activate output alarm if 1AL0 = 4, 5, 6: 0 = Output alarm, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0...12	0
1AL 3	Alarm or interlock mode OFF = Alarm mode active: Icon and the words ALA# on the small digits indicating active alarm will appear on display, reset option in 1AL4 applies. ON = Interlock mode: Outputs revert to normal operation when alarm condition is no longer present, Icon and text indicating active alarm will not appear.	OFF, ON	OFF (Alarm)
1AL 4	Automatic reset or acknowledge to reset (only if AL3 = OFF) OFF = Alarm condition resets automatically. After alarm condition is no longer present, outputs will revert to normal operation, but alarm Icon will continue to blink on display until acknowledged with Option key. ON = Alarm condition must be reset manually. After alarm condition is no longer present, outputs will remain in alarm setting, and Icon will continue to blink on display, until acknowledged with Option key. Note: All alarms operate as well if the controller is in OFF mode.	OFF, ON	OFF (Automatic reset)
	Select if interlock is active in OFF mode (only if AL3 = ON) OFF = Interlock is not active while controller is in off mode or disabled ON = Interlock is active independent of controller state		
1AL 5	Delay until alarm is active	00:00s...15:10h MM:SS...HH:MM	00:00 MM:SS
1AL 6	Type of feedback (applies only if AL0 = 4, 5, 6, 8) OFF = Direct: Output on, feedback high ON = Reverse: Output on, feedback low	OFF, ON	OFF
1AL 7	Alarm limit for input based alarms (applies only if AL0 = 1, 4 to 6 in feedback mode) Note: shared value. Changing this input will as well change 1AL9	Per input range	10%
1AL 8	Hysteresis for alarm setback for input based alarms (applies only if AL0 = 1) Note: shared value. Changing this input will as well change 1ALA	Per input range	5%
1AL 9	Alarm limit for sequence based alarms (applies only if AL0 = 4 to 6 in output mode, 7) Note: shared value. Changing this input will as well change 1AL7	0...100%	8%
1AL A	Hysteresis for alarm setback for sequence based alarms (applies only if AL0 = 4 to 6 in output mode or 7) Note: shared value. Changing this input will as well change 1AL8	0...100%	4%

→ Feedback alarms for fans, binary and analog outputs (AL0 = 4-6):

Feedback alarms are deployed to make sure a device is operating correctly. For example, to supervise a fan feedback from a pressure switch may be used. While the fan is in operation, the pressure should be high, if the fan is off, the pressure should be low. If any of these conditions is amiss, after the delay time defined in AL5 expired, an alarm needs to be generated. Feedback alarms normally should not reset themselves automatically, therefore set AL4 = ON.

→ Output alarms for fans, binary and analog outputs (AL0 = 4-6):

Output alarms or interlocks can be used to activate an interlock based on the activation of, or exceeding the limit of, an output. A feedback alarm with no input assigned (AL2 = 0) will work as an output alarm or interlock.

For fan output alarms, each fan speed has a value of 10%. So speed 1 = 10%, speed 2 = 20% and speed 3 = 30%. To trigger an interlock or alarm based on fan speeds, the appropriate limits will have to be set using AL9 and AL10.

For binary outputs, the level is 100% when on and 0% when the output is off.

Analog outputs are according to their actual output level in % of the full span.

Alarms based on control loop sequence

1AL 0	Select alarm type: 0 = Alarm is not active 1 = Input high or low limit (Select input in AL 2) 2 = Max. set point deviation of control loop (select loop in AL 1) 3 = Maintenance alarm from run time counters (select counter in AL 1) 4 = Feedback or output alarm for fan, supervise fan state (Select fan in AL 1) 5 = Feedback or output alarm for binary output (select output in AL 1) 6 = Feedback or output alarm for analog output (select output in AL 1) 7 = Level alarm or interlock for PI-sequence of control loop 8 = Timeout or cycle mode for outputs. (select type in AL 2 and ID in AL 1)	0...8	0
1AL 1	Select control loop if 1AL 0 = 2,7, Note: max deviation limit is defined in control loop parameters 0 = all active control loops (not valid if 1AL0 = 7) 1 = loop 1 to 4 = loop 4	0...8	0
1AL 2	Select sequence if 1AL0 = 7 0 = heating or reverse 1 = cooling or direct 2 = heating and cooling or reverse and direct	0...15	0
1AL 3	Alarm or interlock mode OFF = Alarm mode active: Icon and the words ALA# on the small digits indicating active alarm will appear on display, reset option in 1AL4 applies. ON = Interlock mode: Outputs revert to normal operation when alarm condition is no longer present, Icon and text indicating active alarm will not appear.	OFF, ON	OFF
1AL 4	Automatic reset or acknowledge to reset (only if AL3 = OFF) OFF = Alarm condition resets automatically. After alarm condition is no longer present, outputs will revert to normal operation, but alarm Icon will continue to blink on display until acknowledged with Option key. ON = Alarm condition must be reset manually. After alarm condition is no longer present, outputs will remain in alarm setting, and Icon will continue to blink on display, until acknowledged with Option key. Note: All alarms operate as well if the controller is in OFF mode. Select if interlock is active in OFF mode (only if AL3 = ON) OFF = Interlock is not active while controller is in off mode or disabled ON = Interlock is active independent of controller state	OFF, ON	OFF
1AL 5	Delay until alarm is active	00:00s...15:10h MM:SS...HH:MM	00:00 MM:SS
1AL 6	Type of alarm (applies only if AL0 = 1, 7) OFF = Low limit alarm ON = High limit alarm	OFF, ON	OFF
1AL 7	Not used	Per input range	10%
1AL 8	Not used	Per input range	5%
1AL 9	Alarm limit for sequence based alarms (applies only if AL0 = 4 to 6 in output mode, 7) Note: shared value. Changing this input will as well change 1AL7	0...100%	8%
1AL A	Hysteresis for alarm setback for sequence based alarms (applies only if AL0 = 4 to 6 in output mode or 7) Note: shared value. Changing this input will as well change 1AL8	0...100%	4%

→ Alarms or interlocks for PI sequences of control loops (AL0 = 7)

Set an alarm or interlock if a sequence of a control loop exceeds a certain level. This may be used to control an output through several control conditions in parallel when applied as interlock, or to indicate a malfunctioning control setup when used as alarm. Use limits AL9 and ALA to define limit and hysteresis for alarms or interlocks for PI sequences.

→ Alarm notification or interlock (AL3):

Low or high limits of inputs may be used to supervise operating conditions when an output should be switched on or off independent of control situations. In this case an alarm display may be unwanted. The display of an alarm can be suppressed by converting the alarm to an interlock by setting AL3 to ON.

Timeout or cycle mode for outputs

1AL 0	Select alarm type: 0 = Alarm is not active 1 = Input high or low limit (Select input in AL 2) 2 = Max. set point deviation of control loop (select loop in AL 1) 3 = Maintenance alarm from run time counters (select counter in AL 1) 4 = Feedback or output alarm for fan, supervise fan state (Select fan in AL 1) 5 = Feedback or output alarm for binary output (select output in AL 1) 6 = Feedback or output alarm for analog output (select output in AL 1) 7 = Level alarm or interlock for PI-sequence of control loop (select output in AL 1) 8 = Timeout or cycle mode for outputs.	0...8	0
1AL 1	Select fan, binary or analog output if 1AL 0 = 4, 5, 6, 8 0 = Interlock or alarm not active 1..x = selected output	0...8	0
1AL 2	Select type of device for timeout detection if 1AL 0 = 8 0 = Operation mode, Active if operation mode is OFF. (revert using AL6) 1 = fan, Active if fan is off 2 = binary output 3 = analog output	0...15	0
1AL 3	Alarm or interlock mode OFF = Alarm mode active: Icon and the words ALA# on the small digits indicating active alarm will appear on display, reset option in 1AL4 applies. ON = Interlock mode: Outputs revert to normal operation when alarm condition is no longer present, Icon and text indicating active alarm will not appear.	OFF, ON	OFF
1AL 4	Automatic reset or acknowledge to reset (only if AL3 = OFF) OFF = Alarm condition resets automatically. After alarm condition is no longer present, outputs will revert to normal operation, but alarm Icon will continue to blink on display until acknowledged with Option key. ON = Alarm condition must be reset manually. After alarm condition is no longer present, outputs will remain in alarm setting, and Icon will continue to blink on display, until acknowledged with Option key. Note: All alarms operate as well if the controller is in OFF mode. Select if interlock is active in OFF mode (only if AL3 = ON) OFF = Interlock is not active while controller is in off mode or disabled ON = Interlock is active independent of controller state	OFF, ON	OFF
1AL 5	Timeout period: time while the output is off. This time will be reset if the output activates.	00:00s...15:10h MM:SS...HH:MM	00:00 MM:SS
1AL 6	Direct or reversed action(apply only if AL0 = 4, 5, 6, 8) OFF = Direct: Output off, cycle detection active ON = Reverse: Output on, cycle detection active	OFF, ON	OFF
1AL 7	Run time in cycle mode. (applies only if AL0 = 8) Interlock or alarm will be activated for the run time specified here.	00:00s...15:10h MM:SS...HH:MM	00:00
1AL 8	Activation in cycle mode. (applies only if AL0 = 8) 0 = function is active independent of operation mode 1 = function is active only in ON mode 2 = function is active only in OFF mode 3 = function is active only in disabled mode 4 = function is active only in OFF and disabled mode.	0...4	0
1AL 9	Not used	0...100%	8%
1AL A	Not used	0...100%	4%

➔ Cycle mode for interlocks or alarms (AL0 = 8)

In cycle mode, the output will activate after a defined timeout period (AL5) for a set period of time (run time, AL7). After the run time has expired, the output will stay off for the timeout period and will activate again after it has expired and so forth.

- ➔ Normally an output is activated which is inactive during the timeout time. This can be inverted by AL 6. An output is then deactivated, which is active for a long time.
- ➔ The timeout period will restart, should the output activate based on control loop demand or manual interaction during the defined the timeout period.
- ➔ This function can be set with AL8 to be only active during certain operation modes. It can therefore be used either as valve cycle or as humidity or mould control feature. Important is to keep AL4 = ON if the function should be active in OFF or disabled mode.
- ➔ Truth table for cycle activation in interlock mode (AL3 = ON)

	AL4 = OFF	AL4 = ON
AL8 = 0	Only active in on mode	Always active
AL8 = 1	Only active in on mode	Only active in on mode
AL8 = 2	Not active	Only active in off mode
AL8 = 3	Not active	Only active in disabled mode
AL8 = 4	Not active	Only active in off or disabled mode

Control loop configuration

Manipulation of the setpoint

Parameter	Description	Range	Default
1L 00	Select loop control input (0= loop disabled): 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0-15	1
1L 01	Minimum set point limit heating or winter mode	per input range	0%
1L 02	Maximum set point limit heating or winter mode	per input range	100%
1L 03	Minimum set point limit cooling or summer mode	per input range	0%
1L 04	Maximum set point limit cooling or summer mode	per input range	100%
1L 05	Enable set point compensation. Setpoint compensation is further described in auxiliary function 4FU. 0= disabled 1= winter compensation 2= summer compensation 3= winter and summer	0-3	0
1L 06	Select loop setpoint (0= normal): 1 = combine setpoint with previous control loop 2 = cascade with reverse sequence of primary loop 3 = cascade with direct sequence primary loop 4 = cascade with both reverse and direct sequence of primary loop 5 = UI1 (percentage of input value is spanned between set point limits) 6 = UI2 (percentage of input value is spanned between set point limits) 7 = UI3 (percentage of input value is spanned between set point limits) 8 = UI4 (percentage of input value is spanned between set point limits) 9 = UI5 (percentage of input value is spanned between set point limits) 10 = UI6 (percentage of input value is spanned between set point limits) 11 = UI7 (percentage of input value is spanned between set point limits) 12 = UI8 (percentage of input value is spanned between set point limits) Note: for input based setpoints: input must be set to 0-100% or in potentiometer mode.	0-12	0
1L 07	X _{SBY} : Unoccupied mode setpoint shift If 1L27 = OFF, the occupied setpoint is shifted by the value set with this parameter. The heating set point is reduced and the cooling set point is increased.	Per input range	5%
1L 08	X _{DZ} : Dead zone between displayed set point in 4-pipe mode and acting setpoint In 4-pipe mode, if both heating and cooling sequences of a loop are enabled, the center setpoint is shown on the display.	Per input range	2%
1L 09	Choose alarm or interlock to set disable control loop. If any of the selected alarms is active, the control loop will be disabled. All connected outputs will be off or 0%. ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1L 27	Fixed set point in unoccupied mode OFF = In unoccupied mode, set point is shifted according to 1L07 ON = In unoccupied mode use minimum set point limit as set point in heating mode or maximum set point limit in cooling mode	ON/OFF	OFF
1L 28	Set point limits selection based on summer winter OFF = Set point limits follow heat – cool setting of control loop ON = Set point limits follow summer – winter flag (UP 24)	ON/OFF	OFF

→ Unoccupied mode setpoints:

There are two possibilities to change the setpoint in unoccupied mode: Shift it by L07 or switch to the minimum setpoint limit in heating mode and maximum setpoint limit in cooling by setting 1L27 to ON. Unoccupied mode may be disabled by setting UP06 to OFF.

→ Setpoint compensation:

The setpoint compensation is typically used to compensate the set point due to a change in outside temperature. Enable summer or winter set point compensation for this control loop with L05. Both setpoint shift or setpoint setback are possible. They are described in more detail under auxiliary function 4FU.

→ Display of setpoint value:

Depending on the configuration of the controller there are various set points that might be active. If the control loop is in heating only or cooling only setup, this means if only one sequence is enabled, the acting setpoint is shown. If both sequences are enabled, the controller is in 4-pipe mode. In this case the set point shown is the setpoint which lies between the acting heating and cooling setpoints. The distance between the displayed setpoint and the acting setpoint is called dead zone (1L08). In unoccupied mode, the acting setpoint is shown in all cases.

→ Controlling the setpoint through a potentiometer or input:

Select the input to be used with xL06. The selected input must be set to 0-100% or be in potentiometer mode. The value of the input will then be spanned between the upper and lower setpoint limits of the active mode (heating, cooling or summer, winter). A value of 0% of the input will then result in the set point to match the lower limit and a value of 100% results in the setpoint being identical to the upper limit. The values in between are adjusted proportionally.

Heating / cooling – reverse / direct sequence.

Parameter	Description	Range	Default
1L 24	Activation of reverse/direct (heat/cool) sequence OFF= activates based on demand ON = follows heat/cool state of controller: Set manually or by auxiliary function (3FU)	ON/OFF	OFF
1L 25	Delay for heat/cool changeover in case above parameter is OFF. This delay prevents frequent switching of sequences.	00:00s...15:10h MM:SS...HH:MM	05:00 MM:SS
1L 26	Max allowed set point deviation (will generate an alarm if enabled in alarm parameters), Disabled if set to 0.	per input	0.0

→ Cascade control:

In cascade control (L06) the setpoint of the secondary loop is determined by the demand of the primary loop. The setpoint of the secondary loop is calculated proportionally according to demand of the primary loop between minimum and maximum setpoint limits. Cascade control is activated by setting the parameter XL06 of the secondary control loop.

A typical application is a variable air volume system where the temperature output determines the pressure set point.

Cascade Control Example – VAV Application	
Primary loop = temperature (1L)	Secondary loop = airflow/pressure (2L)
	Settings: 2L01=20%, 2L02=60%, 2L06=2
Depending on temperature set point, the demand is calculated for loop 1. For example 40%.	Based on demand of loop 1, the set point of pressure loop is calculated proportionally between min (20%) and max (60%) pressure set point limits. A demand of 40% will result in a set point of 36% in the above example.

→ Manual override

The set point of cascaded control loops may be manually overridden if not disabled with UP02. Such an override will not reset automatically. To reset back to auto mode, change the set point again while in manual mode and it will return to auto.

→ Activation of reverse / direct sequence

The active sequence for each loop which has both sequences assigned to an output may be determined either by demand or by following the heat / cool mode of the controller. The heat cool mode of the controller can either be set manually or with the auxiliary function FU3.

→ Summer / winter mode:

For 4-pipe systems it is useful to control the setpoint limits by a summer – winter flag instead of heating – cooling mode. To have set point limits follow summer winter instead of heating/cooling, enable xL28. Set point limits now follow the setting of UP24 (summer / winter mode).

→ Max set point deviation

This parameter defines the acceptable limit for the deviation alarm. In the alarm setup it is possible to trigger an alarm or an interlock if the set point does not reach the acceptable limit within a certain time. This can be used to indicate a mal function or to trigger additional booster outputs.

PI control sequence

Parameter	Description	Range	Default
1L 10	X _{OP} : Offset for PI sequence	per input range	0%
1L 11	X _{PH} : P-band heating	per input range	2%
1L 12	X _{PC} : P-band cooling	per input range	2%
1L 13	Integral gain heating (0.1 steps) low= slow reaction, high= fast reaction	0-25.5	0.0
1L 14	Integral gain cooling (0.1 steps)	0-25.5	0.0
1L 15	Measuring interval integral (seconds) low= fast reaction, high value= slow reaction	0-255	1 sec.

→ Activating control loops

Control loops and sequences are activated by assigning outputs to them in the output configuration section.

→ Proportional control (P-band):

The proportional control function calculates the output based on the difference between setpoint and input. The proportional band (P-band) defines the difference between setpoint and input required to produce a 100% output. For example: a heating control sequence and a 2.0°C (4.0°F) P-band value will produce a 10V output (100%) when the input temperature is 2.0°C (4.0°F) below setpoint. This is the working range of the proportional control sequence. With 1°C (2°F) below setpoint, the output will be 5V (50%).

Setting the proportional band to 0 disables proportional control. This is required for very fast control systems such as fan control through air pressure transmitters.

→ Integral control:

Proportional control is in most cases a very stable control mode. The flaw of proportional control alone, however, is that the setpoint is normally not reached. As the measured value gets closer to the setpoint, the output reduces until it reaches a point, a fraction above or below the setpoint, where the output equals the load. To reach the setpoint and achieve a higher level in comfort, the integral function should be activated.


→ Integral Gain (KI) and Measuring Interval TI.

The difference between measured value and setpoint is multiplied with the integral gain factor KI and added to the output. This calculation is done every measuring interval. The measuring interval is defined by TI.

The challenge is to prevent hunting, where the output increases too fast and the temperature overshoots the setpoint. Hunting may result if the integral gain is too high or measuring interval too short. Each system is different. To prevent instability the P-band should be extended when integral gain is active (L14 or L15 set above 0).

Setting the integral gain to 0 disables integral and differential control.

Recommended Values						
	heating (air)	heating (radiant)	humidifying	cooling	dehumidifying	pressure
P-band	2°C(4°F)	1.5°C(3°F)	10%	1.5°C(3°F)	10%	0
Measuring interval (TI)	2	5	15	1	15	1
Integral gain (KI)	0.2	0.1	0.1	0.2	0.1	0.3



Switching binary outputs based on PI sequence:

Binary outputs and fans can now directly correspond to PI levels. In order to achieve this, select the required loop, sequence and switching level with the output parameter of the corresponding binary output or fan.


Digital control sequence

Parameter	Description	Range	Default
1L 16	Action of stages: 0= cumulative: stage 1 stays on when 2 comes on 1= single: stage 1 turns off when 2 comes on 2= digital: stage 1 only, stage 2 only, then stage 1 plus 2	0-2	0
1L 17	X _{OBH} : Offset for heating/reverse binary sequences. Offset shifts the acting set point away from the displayed or saved set point	per input	0%
1L 18	X _{OBC} : Offset for cooling/direct binary sequences. Offset shifts the acting set point away from the displayed or saved set point	per input	0%
1L 19	X _{SH} : Switching span heating. Switching span is the difference between set point and measured value required for the next binary stage to activate.	per input	2%
1L 20	X _{SC} : Switching span cooling. Switching span is the difference between set point and measured value required for the next binary stage to activate.	per input	2%
1L 21	X _H : Switching hysteresis	per input	0.5%
1L 22	Switching delay min running time for binary stage	00:00s...15:10h MM:SS...HH:MM	00:10 MM:SS
1L 23	Switching delay min stopping time for binary stage	00:00s...15:10h MM:SS...HH:MM	00:10 MM:SS
1L 24	Activation of reverse/direct (heat/cool) sequence OFF= activates based on demand ON = follows heat/cool state of controller: Set manually or by auxiliary function (3FU)	ON/OFF	OFF
1L 25	Delay for heat/cool changeover in case above parameter is OFF	00:00s...15:10h MM:SS...HH:MM	05:00 MM:SS
1L 26	Max allowed set point deviation (will generate an alarm if enabled in alarm parameters), Disabled if set to 0.	per input	0.0

- Cumulative stage action (L16=0) is typically used in electric heat applications, and single stage action (L16=1) in fan speed applications. Digital stage action (L16=2) is especially useful in electric heat applications to generate three steps with just two outputs. For example: Step 1=100W, step 2=200W, step 3=300W.

	Cumulative	Single	Digital
Stage 1	Q ₁	Q ₁	Q ₁
Stage 2	Q ₁ +Q ₂	Q ₂	Q ₂
Stage 3			Q ₁ +Q ₂

- Switching hysteresis (L21) is the difference between switching on and switching off. A small hysteresis will increase the number of switching cycles and thus the wear on associated equipment.
- With minimum running time delay (L22) cumulative stages will not switch on simultaneously. With a sudden demand or initial startup, power stage 2 will not start earlier than 10 seconds (default value) after stage 1 has been initiated. Likewise, after a stage is switched off, it will remain switched off until L23 is expired. This is to avoid rapid switching.



Configuration of analog outputs

Analog output general information

- ➔ Set jumpers on the back of the controller: 0–10VDC (default), or 0–20mA. Further define analog output signals with A02. Custom ranges can be created by setting minimum and maximum signal limits.
- ➔ A control loop, special function, digital control or analog control sequence is not active until it is assigned to an output.

Alarms with analog outputs

Parameter	Description	Range	Default
1A 07	Choose alarm to set output to 100% (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 08	Choose alarm to set output to 0%. (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8 Note: setting the same alarm on 1A07 and 1A08 will set output to the level defined in 1A15 if this alarm activates.	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 15	In case the same alarm is selected in 1A07 and 1A08, the output will be set to the here defined level, in case the alarm activates.	0-100%	50%

➔ Alarm or interlock selection:

Every output may be activated or deactivated based on a series of alarms or interlocks. Alarms specify fault conditions of the control application; interlocks may be used to offer additional control options. Alarms operate as well when the controller is in off mode. Interlocks can be selected to be active in off mode or not. To activate the output while an alarm is pending, select the alarm in A07. To deactivate the output with the alarm pending, select it in A08. If both an alarm is active which is selected in A07 and another alarm is active that is selected in A08, the output will be switched off.

➔ Specific output level for alarms or interlocks.

Selecting the same alarm for both 0% and 100% output will activate a special level that can be specified in A15.


Analog output configuration for control loops

Parameter	Description	Range	Default
1A 00	Select control loop or special function: 0 = OFF 1 = Loop 1 2 = Loop 2 3 = Loop 3 4 = Loop 4 5 = Special functions (Dehumidification, Economizer, etc.) 6 = Manual positioning/time schedules (0-100%) 7 = Transmit value of an input (Specify signal with 1A09-1A11) 8 = Max of loop 1 and loop 2	0-8	1
1A 01	When 1A00=1 – 4 configure output: 0= Heating/reverse 1= Cooling/direct 2= Heating and cooling (4 pipe) 3= 100% on if loop in heating mode: Reversing valve mode 4= 100% on if loop in cooling mode: Reversing valve mode 5= Transmit set point: (Specify signal with 1A10 and 1A11)	0-5	0
	When 1A00 = 8 Maximum of output of loop 1 and loop 2 0 = Loop 1: Heating, Reverse Loop 2: Heating, Reverse 1 = Loop 1: Cooling, Direct Loop 2: Heating, Reverse 2 = Loop 1: Heating and Cooling Loop 2: Heating, Reverse 3 = Loop 1: Heating, Reverse Loop 2: Cooling, Direct 4 = Loop 1: Cooling, Direct Loop 2: Cooling, Direct 5 = Loop 1: Heating and Cooling Loop 2: Cooling, Direct		
1A 02	Type of output signal: 0 = 0-10 VDC 1 = 2-10 VDC 2 = 0-20 mA 3 = 4-20 mA	0-4	0
1A 03	Minimum limitation of output signal default and in loop heating mode	0-100%	0%
1A 04	Maximum limitation of output signal default and in loop heating mode	0-100%	100%
1A 05	Minimum limitation of output signal in loop cooling mode	0-100%	0%
1A 06	Maximum limitation of output signal in loop cooling mode	0-100%	100%
1A 07	Choose alarm to set output to 100% (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 08	Choose alarm to set output to 0%. (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8 Note: setting the same alarm on 1A07 and 1A08 will set output to the level defined in 1A15 if this alarm activates.	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 09	If 1A01 = 5, feedback of setpoint, specify Input used in control loop here: 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0...15	0
1A 10	Minimum transmit value of inputs or set points	per input range	0%
1A 11	Maximum transmit value of inputs or set points	per input range	100%
1A 12	In loop sequence mode: Span PI sequence: lower limit of PI sequence. Loop sequence mode is entered when the analog output is assigned to a loop in A00 and a sequence with A01. With this setting, the sequence may now be spanned over different outputs. For example AO1 0-50% and AO2 50-100%.	0-100%	0%
1A 14	In loop sequence mode: Span PI sequence:: upper limit of PI sequence. See 1A12 for explanation.	0-100%	100%
1A 15	In case the same alarm is selected in 1A07 and 1A08, the output will be set to the here defined level, in case the alarm activates.	0-100%	50%

→ it is now possible to only use a part of a PI signal for one analog output. The signal is then spanned to the full output range. For example AO1 outputs 0-10V if the PI signal is 0% - 50%; AO2 outputs 0-10V if the PI signal is 50% - 100%. Set the limits with 1A12 and 1A14.

Note: For normal operation with one analog output per sequence A12 must be 0% and A14 %

→ For **VAV Function** individual minimum and maximum limits may be assigned for cooling and heating. In VAV applications maximum cooling output matches the maximum air volume the VAV box is set to deliver. As demand for airflow in cooling mode decreases, airflow dwindles until it reaches minimum cooling output (1A05). This minimum will be based on the airflow needed at design cooling and is typically 10% to 15% of maximum cooling airflow. When this minimum is reached the system is in dead-band – neither heating nor cooling. Minimum airflow in heating mode is set with 1A03. As the system moves into heating mode, heating airflow increases until it reaches the maximum heating output (1A04), typically 30 to 50% of maximum cooling airflow.



Analog output configuration for special functions and manual control

Parameter	Description	Range	Default
1A 00	Select control loop or special function: 0 = OFF 1 = Loop 1 2 = Loop 2 3 = Loop 3 4 = Loop 4 5 = Special functions (Dehumidification, Economizer, etc.) 6 = Manual positioning/time schedules (0-100%) 7 = Transmit value of an input (Specify signal with 1A09-1A11) 8 = Max of loop 1 and loop 2	0-8	1
1A 01	When 1A00=5, select function: 0 = Dehumidification: Max of loop 1 cooling and loop 2 dehumidifying sequence. See detail application note below. 1 = Economizer: Outdoor damper actuator. See 5FU for more details. 2 = Economizer: Return air damper actuator. See 5FU for more details.	0-5	0
	When 1A00 = 6 Manual positioning/time schedules 0 = Allow time schedule only 1 = Allow manual positioning and time schedules		
1A 02	Type of output signal: OFF= 0-10V, 0-20mA, ON= 2-10V, 4-20mA	ON/OFF	OFF
1A 03	Minimum limitation of output signal default and in loop heating mode	0-100%	0%
1A 04	Maximum limitation of output signal default and in loop heating mode	0-100%	100%
1A 05	Minimum limitation of output signal in loop cooling mode	0-100%	0%
1A 06	Maximum limitation of output signal in loop cooling mode	0-100%	100%
1A 07	Choose alarm to set output to 100% (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 08	Choose alarm to set output to 0%. (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8 Note: setting the same alarm on 1A07 and 1A08 will set output to the level defined in 1A15 if this alarm activates.	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 12	In loop sequence mode: Span PI sequence: lower limit of PI sequence. Loop sequence mode is entered when the analog output is assigned to a loop in A00 and a sequence with A01. With this setting, the sequence may now be spanned over different outputs. For example AO1 0-50% and AO2 50-100%.	0-100%	0%
1A 14	In loop sequence mode: Span PI sequence:: upper limit of PI sequence. See 1A12 for explanation.	0-100%	100%
1A 15	In case the same alarm is selected in 1A07 and 1A08, the output will be set to the here defined level, in case the alarm activates.	0-100%	50%

➔ With manual positioning (1A00=6) position the output by time schedule or directly in 0.5% steps. Setting 1A01 to 0 will disable access to manual positioning through the operation terminal. The output will then only be controlled by time schedule.

➔ **Dehumidification function: A00 = 5 and A01 = 0.**

Set loop 1 as the temperature loop and loop 2 as the humidity loop.

The cooling output is connected to this function, the heating output is assigned to the heating sequence of loop 1.

So for parameters this will look like this:

Cooling output AO1: 1A00 = 5, 1A01 = 0 (cooling loop 1 and dehumidification loop 2);

Heating output AO2: 2A00 = 1, 2A01 = 0 (heating mode)

Analog output transmit value of an input

Parameter	Description	Range	Default
1A 00	Select control loop or special function: 0 = OFF 1 = Loop 1 2 = Loop 2 3 = Loop 3 4 = Loop 4 5 = Special functions (Dehumidification, Economizer, etc.) 6 = Manual positioning/time schedules (0-100%) 7 = Transmit value of an input (Specify signal with 1A09-1A11) 8 = Max of loop 1 and loop 2	0-8	1
1A 02	Type of output signal: OFF= 0-10V, 0-20mA, ON= 2-10V, 4-20mA	ON/OFF	OFF
1A 03	Minimum limitation of output signal default and in loop heating mode	0-100%	0%
1A 04	Maximum limitation of output signal default and in loop heating mode	0-100%	100%
1A 05	Minimum limitation of output signal in loop cooling mode	0-100%	0%
1A 06	Maximum limitation of output signal in loop cooling mode	0-100%	100%
1A 07	Choose alarm to set output to 100% (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 08	Choose alarm to set output to 0%. (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8 Note: setting the same alarm on 1A07 and 1A08 will set output to the level defined in 1A15 if this alarm activates.	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 09	When 1A00 = 7: Select input used for transmitter function. Measured values of any input may be transmitted on this output. 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0-15	0
1A 10	Minimum transmit value of inputs or set points	per input range	0%
1A 11	Maximum transmit value of inputs or set points	per input range	100%
1A 15	In case the same alarm is selected in 1A07 and 1A08, the output will be set to the here defined level, in case the alarm activates.	0-100%	50%

→ **Signal converter and transmitter:** Measured and calculated input values (A00=7) or set points of control loops (A00=1-4 and A01=5) may be transmitted on the analog outputs.

Analog output if used in fan module

Parameter	Description	Range	Default
1A 02	Type of output signal: OFF= 0-10V, 0-20mA, ON= 2-10V, 4-20mA	ON/OFF	OFF
1A 03	Minimum limitation of output signal default and in loop heating mode	0-100%	0%
1A 04	Maximum limitation of output signal default and in loop heating mode	0-100%	100%
1A 05	Minimum limitation of output signal in loop cooling mode	0-100%	0%
1A 06	Maximum limitation of output signal in loop cooling mode	0-100%	100%
1A 07	Choose alarm to set output to 100% (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 08	Choose alarm to set output to 0%. (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8 Note: setting the same alarm on 1A07 and 1A08 will set output to the level defined in 1A15 if this alarm activates.	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1A 12	If analog output is activated in fan module: select output level if fan speed 1 is active	0-100%	0%
1A 13	If analog output is activated in fan module: select output level if fan speed 2 is active	0-100%	50%
1A 14	If analog output is activated in fan module: select output level if fan speed 3 is active	0-100%	100%
1A 15	In case the same alarm is selected in 1A07 and 1A08, the output will be set to the here defined level, in case the alarm activates.	0-100%	50%

→ Analog outputs for fan modules:

An analog output may be assigned to a fan module by selecting 1F09 = ON. In this case above parameters do not apply except 1A02 to 1A06 and 1A12-1A14. The signal type and output levels depending on fan speed need to be selected with those parameters.

Configuration of binary outputs

The binary outputs may be used to control fans, floating point actuators, single stages, or PWM outputs. In case an output is defined for more than one function the following priority applies:

Priority	Physical outputs	DO1	DO2	DO3	DO4	DO5	DO6
1	2 fan outputs up to 3 speeds each: 2 rotation groups:	FAN 1			FAN2		
		speed 1	speed 2	speed 3	speed 1	speed 2	speed 3
		1FA 0 ≥ 1	1FA 0 ≥ 2	1FA 0 = 3	2FA 0 ≥ 1	2FA 0 ≥ 2	2FA 0 = 3
		stage 1	stage 2	stage 3	stage 1	stage 2	stage 3
2	3 floating point outputs:	FO1		FO2		FO3	
		open	close	open	close	open	close
3	6 digital or PWM outputs:	DO1	DO2	DO3	DO4	DO5	DO6

Note: FAN1 or FAN2 modules may as well be assigned to analog outputs. In this case DO1 – DO3 for FAN1 and DO4 – DO6 for FAN2 will be free for other uses.

Fan configuration

Parameter	Description	Range	Default
1F 00	Select the number of fan speeds	0 – 3	0
1F 01	Selection of control loop for fan 0 = Fan output disabled, 1 = Loop 1 2 = Loop 2 3 = Loop 3 4 = Loop 4 5 = Operation mode (on, when operation mode is on, occupied and unoccupied) 6 = Manual positioning/time schedule controlled 7 = Occupied mode (on if occupied, off if unoccupied) 8 = Max of loop 1 and loop 2 9 = Lead-Lag for binary outputs: DO1 → DO2 → DO3	0 – 9	1
1F 02	Fan outputs select active sequence of control loop if F01=1-4 or select active state of controller if F01=5,7: 0 = if 1F01 = 1-4: Heating, Reverse 1 = if 1F01 = 1-4: Cooling, Direct 2 = if 1F01 = 1-4: Heating and Cooling (4 pipe system) 3 = if 1F01 = 5,7: Demand based on Heating, Reverse 4 = if 1F01 = 5,7: Demand based on Cooling, Direct 5 = if 1F01 = 5,7: Demand based on Heating and Cooling When F01 = 6: Manual positioning/time schedules 0 = Allow time schedule only 1 = Allow manual positioning and time schedules When F01 = 8: Maximum of output of loop 1 and loop 2 0 = Loop 1: Heating, Reverse Loop 2: Heating, Reverse 1 = Loop 1: Cooling, Direct Loop 2: Heating, Reverse 2 = Loop 1: Heating and Cooling Loop 2: Heating, Reverse 3 = Loop 1: Heating, Reverse Loop 2: Cooling, Direct 4 = Loop 1: Cooling, Direct Loop 2: Cooling, Direct 5 = Loop 1: Heating and Cooling Loop 2: Cooling, Direct	0 – 5	2
1F 03	Fan behavior when setpoint is satisfied if F01 = 1-8: 0 = Fan off when no demand 1 = Lowest fan speed on when occupied. Fan switches off when not occupied. 2 = Lowest fan speed on in cooling mode. Fan switches off in heating mode. 3 = Lowest fan speed on when operation mode on, occupied and unoccupied (mold protection)	0...3	0

Note: Fan output settings continued on next page.

- ➔ The active fan speed is defined by the binary sequence of the control loop (L17-L23) or if F10= ON the output of the PI sequence of this control loop.
Automatic fan speeds can be overridden by keypad if manual mode is enabled (UP02 = ON). If fan should be manually disabled F08 need to be set to ON.
- ➔ Demand based functions: The fan will start automatically in case there is a demand on the heating or cooling sequence of a specific control loop (defined in F01) or the controller if F01=5. Startup and switch off delays will apply.
- ➔ With manual positioning (F01=6) control the fan by time schedule or manually. Setting F02=0 will disable manual positioning through the operation terminal. The fan will then only be controlled by time schedule. Set F02=1 to allow manual positioning.

Startup, switch off delays and alarms

Parameter	Description	Range	Default
1F 04	Startup delay: Delay before starting fan. Other control outputs connected to the same control loop are disabled during startup delay.	00:00s...15:10h MM:SS...HH:MM	00:00s MM:SS
1F 05	Switch off delay: If the fan should extend its run time after the control valves are closed. Set the time to extend fan run time after control outputs switch off.	00:00s...15:10h MM:SS...HH:MM	00:00s MM:SS
1F 06	Choose alarms to set fan to 100%. In case of conflicting alarms, the fan will be switched off. See section alarms for further details. ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1F 07	Choose alarms to switch off fan. See section alarms for further details. ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽

→ Startup and switch off delay.

During the startup or the switch off delay of a fan module all other control outputs assigned to control loop 1 for fan module 1 or control loop 2 for fan module 2, will be deactivated. This prevents overheated electrical heating batteries for example.

→ Alarm or interlock selection:

Every may be activated or deactivated based on a series of alarms or interlocks. Alarms specify fault conditions of the control application; interlocks may be used to offer additional control options. Alarms operate as well when the controller is in off mode. Interlocks can be selected to be active in off mode or not.

To activate the output while an alarm is pending, select the alarm in F07. To deactivate the output with the alarm pending, select it in F08. If both an alarm is active which is selected in F07 and another alarm is active that is selected in F08, the output will be switched off.

Fan output settings for manual control and DO/AO selection

Parameter	Description	Range	Default
1F 08	Manual fan switch off mode When F01 = 1-4 or 6: Manual switch off of fan OFF = Fan may not be switched off manually while assigned to control loop ON = Fan can be set to off manually while assigned to control loop	ON/OFF	OFF
1F 09	Choose output DO or AO: OFF = DO, ON = AO FAN1: OFF = DO1-DO3, ON = AO1 FAN2: OFF = DO4-DO6, ON = AO2 Note: In case F09 = ON, analog output signal must be defined with analog output parameters 1A02 to 1A06 for fan1 or 2A02 to 2A06 for fan2.	ON/OFF	OFF

Fan output configuration in PI mode (F10 = ON)

Parameter	Description	Range	Default
1F10	Use PI sequence as input for fan (not binary sequence)	ON/OFF	OFF
1F11	Limit for fan speed 1 if F10 = ON Note: Shared parameter: Changing this value, will as well change F15.	0...100%	20%
1F12	Limit for fan speed 2 if F10 = ON Note: Shared parameter: Changing this value, will as well change F16.	0...100%	50%
1F13	Limit for fan speed 3 if F10 = ON Note: Shared parameter: Changing this value, will as well change F17.	0...100%	80%
1F14	Hysteresis for fan speeds if F10 = ON	0...100%	15%

→ Maximum of loop 1 and loop 2:

The maximum output value of two control loops may be assigned to one output. A combination of indirect and reverse sequences may be chosen. Applications for this function are CO2 and moisture control for ventilation, dehumidification.

→ Fan module for analog outputs:

This can be useful for EC (electronically commutated) type fans or if external switching modules are used instead of binary outputs.

To use an analog output instead of binary outputs, set F09 to ON and then specify output switching levels. The output switching levels define the analog output generated according to which fan speed. The levels are set in the corresponding analog output settings (A12 to A14). AO1 for Fan1 and AO2 for Fan2.

→ Fan output in PI mode

Switch fan based on PI sequence rather than binary sequence of control loop. Select control loop and sequence with parameters F01 and F02, set F10 = ON and define switching limits for different fan speeds with F11 to F13. The hysteresis for all fan speeds is identical and is set with F14.

Lead-lag configuration

Parameter	Description	Range	Default
1F 00	Total number of lead/lag stages	0 – 3	0
1F 01	Selection of control loop for fan 9 = Lead-lag configuration: OUT1 → OUT2 → OUT3	0 – 9	1
1F 02	In lead-lag mode: Define number of simultaneous active outputs. If set to 0 or 1, then only one output will be active at the same time, if set to 2 then 2 outputs will be active at each time. For this to work at least 3 outputs must be activated.	0 – 5	2
1F 03	In lead-lag mode (F01 = 9): Step length of F15 0 = Steps defined in F15 are counted in minutes 1 = Steps defined in F15 are counted in hours 2 = Steps defined in F15 are counted in days (24h)	0...3	0
1F 04	Startup delay: Delay before starting new stage. Other outputs assigned to same control loop are disabled during delay. Extended delays	00:00s...15:10h MM:SS...HH:MM	00:00s MM:SS
1F 05	Switch off delay: Delay while switching off old stage. Other outputs assigned to same control loop are disabled during delay. Extended delays	00:00s...15:10h MM:SS...HH:MM	00:00s MM:SS
1F 06	Choose alarms to activate all assigned outputs. In case of conflicting alarms, all outputs assigned to the lead – lag module will be switched off. See section alarms for further details. ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1F 07	Choose alarms to switch off fan. See section alarms for further details. ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1F 08	Manual control of output rotation When F01 = 9: Output rotation OFF = Rotation may not be controlled manually ON = Rotation can be controlled manually Note: setting an output to manual while in output rotation mode, will interrupt output rotation indefinite until set back to auto mode.	ON/OFF	OFF
1F15	In output rotation mode (F01 = 9): Running time in minute, hours or days. (Set with F03). While in auto mode, the controller will switch to the next output after this time has expired. Note: Shared parameter: Changing this value, will as well change F11.	0...255	50
1F16	If F01 = 9: Current active output (1-3) Note: Shared parameter: Changing this value, will as well change F12.	0-3	-
1F17	If F01 = 9: Run time in minute, hours or days (set with F03) for current of output since last switch. Note: Shared parameter: Changing this value, will as well change F13.	0....255	-

→ Lead – lag configuration:

The fan module may be used to rotate a group of binary outputs based on their run time. This is commonly used with pumps or where multiple devices control one function. To use lead-lag, activate it by selecting number of outputs involved with F00, choose function by setting F01 = 9. The number of simultaneous active outputs is set with F02 (1 or 2). Choose running time step size with F03 for minutes, hours or days and set running time of each output with F15 (Step size may only be defined with V1.2R4 and later).

Select if manual control is allowed with F08. The current active output may now be seen in F16, the current running time since the last switch is visible with F17. These settings and times may be changed through access to parameters. Note: Parameters F10 to F14 may change while this mode is active.

→ Configure demand based operation and supervision of each output during lead-lag mode:

If the binary outputs are assigned to the lead lag module, they can now have lag and disable interlocks assigned to them. Assign a maximum delay alarm to an interlock and then assign this interlock to the lead lag module for simultaneous activation of all its outputs.

→ Assign an alarm input to an interlock and then assign this interlock to the disable parameter of the individual outputs. If the lead output is disabled, the lag output will be activated instead.

→ Following options are possible: Lead – Lag, Lead – Lag – Lag, Lead – Lead – Lag, Lead – Lead – Lead. They can be changed during operation with interlocks. Additionally there is a standby output that can replace any of the outputs.

Floating output configuration

Parameter	Description	Range	Default
1d 00	Enable digital or floating point output 1d00 = OFF: DO1, DO2 are two digital/PWM outputs 1d00 = ON : DO1, DO2 is one floating point output (DO1 open, DO2 close)	ON/OFF	OFF
1d 01	Select control loop or special function (0= OFF) 1 = Loop 1 2 = Loop 2 3 = Loop 3 4 = Loop 4 5= Special functions (Dehumidification, Economizer, etc.) 6= Manual positioning/time schedule controlled 7= Controller state functions 8 = Max of loop 1 and loop 2 9 = Proportional function: Output assigned to an input 10 = Not used	0-9	0
1d 02	When 1d01=1-4 configure output: 0= Heating/reverse 1= Cooling/direct 2= Heating and cooling (2 pipe) 3= 100% on if loop in heating mode: Reversing valve mode 4= 100% on if loop in cooling mode: Reversing valve mode	0-15	0
	When 1d01=5, select function: 0 = Dehumidification: Max of loop 1 cooling and loop 2 dehumidifying sequence. 1 = Economizer: Outdoor air damper actuator. See 5FU for more details. 2 = Economizer: Return air damper actuator. See 5FU for more details.		
	When 1d01 = 6 Manual positioning/time schedules 0 = Allow time schedule only 1 = Allow manual positioning and time schedules		
	When 1d01=7 select state functions: 0= ON if controller operation state is ON 1= ON while demand on any output 2= ON while controller in heating mode 3= ON while controller in cooling mode 4= ON if controller state is occupied, OFF if unoccupied		
	When 1d01 = 8 Maximum of output of loop 1 and loop 2 0 = Loop 1: Heating, Reverse Loop 2: Heating, Reverse 1 = Loop 1: Cooling, Direct Loop 2: Heating, Reverse 2 = Loop 1: Heating and Cooling Loop 2: Heating, Reverse 3 = Loop 1: Heating, Reverse Loop 2: Cooling, Direct 4 = Loop 1: Cooling, Direct Loop 2: Cooling, Direct 5 = Loop 1: Heating and Cooling Loop 2: Cooling, Direct		
	When 1d01 = 9: Select input for proportional function. Minimum and maximum limits are defined with 1d14 and 1d15: 0 = off, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4		
1d 03	When 1d01=6, 7 and 9: Select reaction on on/off/disable operation mode 0 = output is off, when operation mode is off 1 = output is off, when operation mode is disabled 2 = operation mode has no effect on output	0-6	0
1d 04	Running time (Time for actuator to run from fully open to fully close)	00:00s...15:10h MM:SS...HH:MM	00:00s MM:SS
1d 05	Switching difference for floating point signal: to reduce the switching frequency of the actuator. The actuator will only move if the running time to move the actuator from its current position to the target position is larger than this parameter.	00:00s...15:10h MM:SS...HH:MM	00:05s MM:SS

This table is continued on next page.

- ➔ With manual positioning (d01=6) position the output by time schedule or manually (0...100% in 0.5% steps). Setting d02 to 0 will disable manual positioning. The output will then only be controlled by time schedule. Set d02 to 1 to activate manual control of the output.
- ➔ For floating point outputs the running time of the actuator used needs to be specified with 1d04. Running time is defined as the time required for the actuator to run from fully open to fully closed and vice versa. Actuators with a fixed running time are recommended. Once fully open or fully closed the running time for the actuator is extended for a full run-time cycle. This will allow the actuator position to be synchronized in case it has been moved during off time or an actuator with variable running time was used.
- ➔ State functions (1d01=7) fully open the output based on certain conditions with or without a demand for heating or cooling. In Energy Hold OFF mode (EHO) the output will be off.
Note: From V1.2R6 onwards, this function is combined with d03.
- ➔ **Maximum of loop 1 and loop 2:**
The maximum output value of two control loops may be assigned to one output. A combination of indirect and reverse sequences may be chosen. Applications for this function are CO2 and moisture control for ventilation, dehumidification.

Floating outputs configuration continued



Parameter	Description	Range	Default
1d 06	Not used		
1d 07	Choose alarm to set output to 100% (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1d 08	Choose alarm to set output to 0% (output 0% on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1d 09	Not used	ON/OFF	OFF
1d 10	Not used	0...12750h	0
1d 11	Not used	ON/OFF	OFF
1d 12	Not used	0...100%	0%
1d 13	Not used	0...100%	0%
1d 14	Proportional function based on input (1d01 = 9): Minimum limit : If 1d15 > 1d14: when input value is above this limit, output starts to increase. If 1d15 < 1d14: when input value is below this limit, output starts to increase. Note: shared parameter: changing this value, will change as well 1d12	0...100%	0%
1d 15	Proportional function based on input (1d01 = 9): Maximum limit : If 1d15 > 1d14: when input value is above this limit, output is at 100%. If 1d15 < 1d14: when input value is below this limit, output is at 100%. Note: shared parameter: changing this value, will change as well 1d13	0...100%	0%

→ Alarm or interlock selection:

Every may be activated or deactivated based on a series of alarms or interlocks. Alarms specify fault conditions of the control application; interlocks may be used to offer additional control options. Alarms operate as well when the controller is in off mode. Interlocks can be selected to be active in off mode or not. To activate the output while an alarm is pending, select the alarm in d07. To deactivate the output with the alarm pending, select it in d08. If both an alarm is active which is selected in d07 and another alarm is active that is selected in d08, the output will be switched off.

→ Proportional function based on input:

The position of a floating output may be based on an input value. The input is selected with d02. Two limits define the proportional range: A minimum and a maximum limit. Depending on this limits the output may be opened with a sinking or a rising input signal.



Binary output configuration (d00=OFF)

Parameter	Description	Range	Default
1d 01	Select control loop or special function (0= OFF) 1 = Loop 1 2 = Loop 2 3 = Loop 3 4 = Loop 4 5= Special functions (Dehumidification, Economizer, etc.) 6= Manual positioning/time schedule controlled 7= Controller state functions 8 = Max of loop 1 and loop 2 9 = Binary output assigned to an input 10 = Binary output assigned to lead/lag module	0-10	0
1d 02	When 1d01=1-4 configure output in loop mode: 0= Heating/reverse 1= Cooling/direct 2= Heating and cooling (2 pipe) 3= On if loop in heating mode: Reversing valve mode 4= On if loop in cooling mode: Reversing valve mode 5= On while demand in heating or cooling mode	0-15	0
	When 1d01=5, select function: 0 = Dehumidification: Max of loop 1 cooling and loop 2 dehumidifying sequence. 1 = Economizer: Outdoor air damper actuator. See 5FU for more details. 2 = Economizer: Return air damper actuator. See 5FU for more details.		
	When 1d01 = 6 Manual positioning/time schedules 0 = Allow time schedule only 1 = Allow manual positioning and time schedules		
	When 1d01=7 select state functions: 0= ON if controller operation state is ON 1= ON while demand on any output 2= ON while controller in heating mode 3= ON while controller in cooling mode 4= ON if controller state is occupied, OFF if unoccupied NEW!		
	When 1d01 = 8 Maximum of output of loop 1 and loop 2 0 = Loop 1: Heating, Reverse Loop 2: Heating, Reverse 1 = Loop 1: Cooling, Direct Loop 2: Heating, Reverse 2 = Loop 1: Heating and Cooling Loop 2: Heating, Reverse 3 = Loop 1: Heating, Reverse Loop 2: Cooling, Direct 4 = Loop 1: Cooling, Direct Loop 2: Cooling, Direct 5 = Loop 1: Heating and Cooling Loop 2: Cooling, Direct		
	When 1d01 = 9: Select input for switch function. Switching limits are defined with 1d14 and 1d15: 0 = off, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4		
	When 1d01 = 10: Select module for lead/lag module. 0 = module 1 not demand based 1 = module 1, if demand on loop 1, heating only 2 = module 1, if demand on loop 1, cooling only 3 = module 1, if demand on loop 1 heating & cooling 4 = module 2 not demand based 5 = module 2, if demand on loop 2, heating only 6 = module 2, if demand on loop 2, cooling only 7 = module 2, if demand on loop 2 heating & cooling		
1d 03	When 1d01=1-4: Select sequence 0 = Operation mode, Output is active when mode is active 1 = binary mode: Stage 1 to 6 = binary mode: Stage 6	0-6	0
	When 1d01=6, 7 and 9: Select reaction on on/off/disable operation mode 0 = output is off, when operation mode is off 1 = output is off, when operation mode is disabled 2 = operation mode has no effect on output		
	When 1d01=10 Select stages for lead - lag module 0 = standby (only for lead - lag module) 1 = output 1 2 = output 2 3 = output 3		
1d 04	Switch off delay: Time the output signal needs to be off, before output switches off In PWM mode: Frequency if energy limiting time is reached.	00:00s...15:10h MM:SS...HH:MM	01:30
1d 05	Switch on delay: Time the output signal needs to be on, before output switches on. With state functions, all control outputs are disabled during switch ON delay. In PWM mode: Energy-limiter: Maximum ON time for PWM outputs, Output will be limited to be active during the time indicated here. After the value is exceeded, it will switch on and off based on frequency defined with 1d04. Note: setting this value to 00:00 deactivates the time limitation.	00:00s...15:10h MM:SS...HH:MM	00:05
1d 06	Activate PWM, set cycle time, seconds (>0 activates, 0 deactivates)	00:00s...15:10h MM:SS...HH:MM	00:00

- ➔ State functions (1d01=7) activate the output based on certain conditions with or without a demand for heating or cooling, in either occupied or unoccupied mode. In OFF mode the output will be off.
Note: From V1.2R6 onwards, this function is combined with d03.

Binary output configuration continued

Parameter	Description	Range	Default
1d 07	Choose alarm to set output to ON (output OFF on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1d 08	Choose alarm to set output to OFF (output OFF on conflicting alarms) ▽▽▽▽▽▽▽▽ Alarm: 1 2 3 4 5 6 7 8	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽
1d 09	d09 and d10 only function if output is in binary mode: OFF: Do not count run time and reset counter to 0 ON: Count run time in hours while a binary output is switched on	ON/OFF	OFF
1d 10	Trigger function alarm when run time is reached (may be used as maintenance alarm), 0 = alarm disabled	0...12750h	0
1d 11	Uses PI sequence instead of binary sequence of PI loop Note: changing this value, will automatically as well change 1d13.	ON/OFF	OFF
1d 12	Activation limit if based on PI (1d01 = 1-4 AND 1d11 = ON), if value above this limit, output switches on. Note: shared parameter: changing this value, will change as well 1d14	0...100%	50%
1d 13	Deactivation limit if based on PI (1d01 = 1-4 AND 1d11 = ON), if value below this limit, output switches off. Note: shared parameter: changing this value, will change as well 1d15	0...100%	40%
1d 14	Activation limit if based on UI (1d01 = 9: if value is above this limit, output switches on. Note: shared parameter: changing this value, will change as well 1d12	0...100%	50%
1d 15	Deactivation limit if based on UI (1d01 = 9: if value is below limit, output switches off. Note: shared parameter: changing this value, will change as well 1d13	0...100%	10%

- ➔ **With manual positioning** (1d01=6) position the output by time schedule or manually (ON, OFF or 0...100% in 0.5% steps for PWM outputs). Setting 1d02 to 0 will disable manual positioning. The output will then only be controlled by time schedule. Set 1d02 to 1 to activate manual control of the output.
- ➔ **Pulse width modulation (PWM) mode** is enabled with 1d06. In PWM mode the digital output will be switched on/off once per cycle. The on and off times are calculated according to the PI settings of the respective control sequence. It is not recommended to use cycle times below 10 Minutes for relays outputs as the lifetime of the relays will be shortened with frequent switching.
- ➔ **Minimum and maximum limits for PWM outputs.** Using d04 and d05 the on time of the PWM signal may now be limited to the value defined with d05. After the limitation has been exceeded the output will cycle with a frequency that is defined with d04. Setting d05 = 00:00 will deactivate the limitation function.
- ➔ **Alarm or interlock selection:**
Every may be activated or deactivated based on a series of alarms or interlocks. Alarms specify fault conditions of the control application; interlocks may be used to offer additional control options. Alarms operate as well when the controller is in off mode. Interlocks can be selected to be active in off mode or not.
To activate the output while an alarm is pending, select the alarm in d07. To deactivate the output with the alarm pending, select it in d08. If both an alarm is active which is selected in d07 and another alarm is active that is selected in d08, the output will be switched off.
- ➔ **Run time counter (d09):**
Run time counters can be used to sum up the accumulated runtime of a device connected to a binary output. The counter runs up to 65536 hours and saves the run time every hour to EEPROM. The run time hours and the status of the binary output will be displayed when stepping through the available display pages with the operation terminal.
- ➔ **Maintenance alarm (d10):**
The run time counter may be used to trigger a maintenance alarm once a certain run time is exceeded. Select limit to trigger a maintenance alarm. The limit is selectable in steps of 256 hours. Setting the time to 0 disables the maintenance alarm. Note: An alarm must be assigned to maintenance alarm by setting AL0 = 3 on one alarm.
- ➔ **Switch binary output based on PI-sequence:**
This Feature allows a direct response to PI output value. So no alarms or interlocks have to be used for a simple limit switch. Switch output based on PI sequence rather than binary sequence of control loop. Select control loop and sequence with parameters d01 and d02, set d11 = ON and define switching limits with d12 and d13.
- ➔ **Switch binary output based on input value:**
Activate the function with d01 = 9. Select the input with d02 and define the switching limits with d14 and d15. Reversing the switching limits, will reverse the switching function of the output.
Note: The switch based on inputs is as well used for the light switch function.
- ➔ **Lead – Lag function:**
The lead – lag function is defined in the fan module. A binary output can be assigned to a lead – lag function. Either as stage that will be rotated based on the settings of the function or as standby output. The standby output will be activated when a stage output fails. Only one standby output can be activated per lead – lag function. Each output assigned to a stage may be disabled using interlocks or alarms. In this case it is disabled, the lead – lag function activates the next stage.


Auxiliary functions

1Fu Enable/disable of controller based on inputs and alarm conditions

Parameter	Description	Range	Default
1Fu 0	Select input for remote enable function: 0 = off, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0...15	0
1Fu 1	Manual override permitted (without waiting for delay). This function allows overriding of the enable conditions by manually starting the controller; The controller will switch off again if the running conditions are not met until the disable delay is expired. This function is required, where the controller needs to create the allowed input condition for example by running a fan while differential pressure is used as enable condition.	ON/OFF	OFF
1Fu 2	Enable delay (seconds) = the time the enable condition must be met before the controller is enabled	00:00s...15:10h MM:SS...HH:MM	05:00 MM:SS
1Fu 3	Disable delay (seconds) = the time the disable condition must be met before the controller is disabled	00:00s...15:10h MM:SS...HH:MM	05:00 MM:SS
1Fu 4	Range of limits (See table below for graphical explanation): OFF = When limit 2 (e.g. 60) is larger than limit 1 (e.g. 40) the controller will be enabled when the input value is greater than limit 2 (e.g. 60) and disabled when the input value is below limit 1 (e.g. 40). When limit 2 (e.g. 40) is lower than limit 1 (e.g. 60) the controller will be enabled when the input value is lower than limit 1 (e.g. 40) and disabled when the input value is above limit 2 (e.g.10). ON = When limit 2 (e.g. 60) is above limit 1 (e.g. 40) the controller will be enabled when the input value is between limit 1(e.g. 40) and limit 2 (e.g. 60). When limit 2 (e.g. 40) is below limit 1 (e.g. 60) the controller will be enabled when the input value is below limit 2 (e.g. 40) or above limit 1 (e.g. 60).	ON/OFF	OFF
1Fu 5	Input limit 1 (See 1Fu 4 for description)	per input range	10
1Fu 6	Input limit 2 (See 1Fu 4 for description)	Per input range	90
1Fu 7	Disable controller in case of selected alarms are active Note: Switch-off delays still apply when an alarm becomes active	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽

→ Enable or disable the controller based on high or low input limits and alarm status. The alarm status register may be used as *and* function where several conditions must be met before the controller is allowed to function.


→ Time schedules do not override the enable function.



2Fu Switch occupied and unoccupied modes based on input values

2Fu 0	Select input: 0 = not active, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0-15	0
2Fu 1	Unoccupied mode delay (seconds) = the time the input needs to be inactive before the controller switches to unoccupied mode.	00:00s...15:10h MM:SS...HH:MM	05:00 MM:SS
2Fu 2	Input limit 1 to signal unoccupied or door opened	per input range	10
2Fu 3	Input limit 2 to signal occupied or door closed	Per input range	90
2Fu 4	Select input for door contact in combination with input defined under 2Fu 0: 0 = not active, 1 = UI 1 to 12 = UI12 If door contact input is defined, the controller will only go to unoccupied mode, if the door is opened and after the door closes, there is no movement registered on the input selected in 2Fu 0	0-12	0
2Fu 5	Select interlocks or alarms for window contact. If any interlock activates, the function will change to unoccupied mode, independent of door state.	Triangle shown = alarm selected	▽▽▽▽▽▽▽▽

- ➔ Use occupied/unoccupied mode changeover with key card switches, occupancy sensors, etc.
Activate function by selecting the input to control occupied/unoccupied mode. Set the limits (2FU2 and 2FU3) to the input values that indicate when the room is occupied or unoccupied. This can be done through a switch or for example a CO2 sensor.
Configure occupied/unoccupied changeover with loop configuration parameter 1L07 and 1L27 for each affected control loop.
- ➔ For door contact applications: The use of a key switch may be avoided by using a door contact and a motion detector. The motion detectors should be placed in each room in order to detect the presence of an occupant. The room will automatically go to unoccupied mode once the door is opened and closed again and if there is no movement in the room after the door closes. The delay of the motion detector MUST therefore be less than the unoccupied mode delay defined with 2FU1; else the controller will stay in occupied mode. Ideal is to keep the delay of the motion detector output to below 30 seconds.
The moment there is movement in the room or the door is opened; the room will go to occupied mode again and will not go to unoccupied unless the door is opened and closed again.
- ➔ Following are the occupied/unoccupied mode switch possibilities:




3Fu Switch heating and cooling state based on input values

Parameter	Description	Range	Default
3Fu 0	Select input for remote heat – cool change function: 0 = not active or based on control loop, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0...15	0
3Fu 1	If heat – cool is based on a control loop, select control loop here (3Fu 0 must be set to 0) 0 = not active or based on universal input 1 = Based on heat – cool status of control loop 1 2 = Based on heat – cool status of control loop 2 3 = Based on heat – cool status of control loop 3 4 = Based on heat – cool status of control loop 4	0...4	0
3Fu 2	Activation delay (Seconds) = delay before heat – cool mode is switched. This delay is to avoid unnecessary switching	00:00s...15:10h MM:SS...HH:MM	05:00 MM:SS
3Fu 3	Input limit 1 (Cool limit) applies only if based on input	Per input range	20%
3Fu 4	Input limit 2 (Heat limit) applies only if based on input	Per input range	40%

➔ The heating or cooling state of the controller may be controlled from a central location by a binary (digital) contact or temperature levels of outside air or supply media. The state may also depend on heating or cooling demand of a control loop. Note: The control loop used to determine the heat /cool state must be set to demand-based heating and cooling with (L24 = OFF).

➔ Set limit 1 and limit 2 to switch between heating and cooling with options below:



➔ When switching heating/cooling state with an external switch set input to RT/DI mode and connect switch to signal ground. Ground levels of all involved controllers must be the same.

➔ For supply media temperature we recommend switching to cooling at limit1 = 16°C/61°F and to heating at limit2 = 28°C/83°F. For outdoor temperature we recommend switching to cooling at limit1 = 28°C/83°F and to heating at limit2 = 16°C/61°F outdoor temperature.


➔ Above recommendations are given as suggestions. The ideal settings may be different on the actual project depending on climatic and system conditions.

4FU Summer/winter compensation of control loop setpoints

Parameter	Description	Range	Default
4Fu 0	Selection of Compensation Input: 0 = not active, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0...15	0
4Fu 1	Type of compensation OFF = Offset: The setpoint shifts up or down based on an input signal ON = Setback: The setpoint is shifted towards loop setpoint min max based on an input signal.	ON, OFF	OFF
Offset setpoint compensation: 4Fu1 = OFF			
4Fu 2	Shift is direct or reverse acting OFF = Direct: Rising input value increases setpoint ON = Reverse: Rising input value decreases setpoint	ON, OFF	OFF
4Fu 3	Input span required to shift setpoint one step: For example: An 4Fu3 value of 5% for a control loop set point with 0.5°C steps will change the set point by 0.5° for every 5% that the compensation input changes.	Per input range	10
4Fu 4	Input where setpoint shift is = 0, This defines the value of the input signal where the control set point is not compensated	Per input range	50
Setback setpoint compensation: 4Fu1 = ON			
4Fu 2	Winter Compensation: OFF = setpoint is shifted negative to lower setpoint limit ON = setpoint is shifted positive to upper setpoint limit	ON, OFF	OFF
4Fu 3	Winter Compensation (Setpoint shift with low compensation signal) Lower Limit: input signal with maximum setpoint shift	Per input range	10
4Fu 4	Winter Compensation (Setpoint shift with low compensation signal) Upper Limit: Input signal at begin of setpoint shift.	Per input range	50
4Fu 5	Summer Compensation: OFF = setpoint is shifted negative to lower setpoint limit ON = setpoint is shifted positive to upper setpoint limit	ON, OFF	ON
4Fu 6	Summer Compensation (Setpoint shift with high compensation signal) Lower Limit: input signal at begin of setpoint shift	Per input range	60
4Fu 7	Summer Compensation (Setpoint shift with high compensation signal) Upper Limit: Input signal with maximum setpoint shift.	Per input range	80
4Fu 8	Hot / Cool Symbol while compensation is active OFF= Hide symbol ON= Show symbol	ON, OFF	OFF

- ➔ Summer/winter compensation changes the set point due to a change in an input value, typically, but not limited to, an outdoor temperature input. Activate summer/winter compensation with control loop configuration parameter (L05).
- ➔ For setpoint setback: Winter compensation starts when outside temperature drops below the upper limit of winter compensation (4FU4). At maximum winter compensation the actual set point will be equal to the control loop's minimum or maximum heating set point depending on the setting of 4FU2. Summer compensation starts when outside temperature exceeds the lower limit for summer compensation (4FU5). At maximum summer compensation the actual set point will be equal to the control loop's minimum or maximum cooling set point depending on 4FU5.
- ➔ Setting 4FU8 = ON indicates the state of compensation on the display by showing a heat – cool symbol.

Set point set back 4FU1 = ON



5Fu: Economizer (free heating or cooling), NEW algorithm!

Parameter	Description	Range	Default
5Fu 0	Assign Economizer to a control loop 0 = economizer function is disabled 1 = assigned to control loop 1 2 = assigned to control loop 2 3 = assigned to control loop 3 4 = assigned to control loop 4	0...4	0
5Fu 1	Assign free heating or/and free cooling options 0 = economizer is disabled 1 = free heating is enabled 2 = free cooling is enabled 3 = free heating and free cooling is enabled	0..3	0
5Fu 2	Outdoor air sensor input (Temperature or Enthalpy): 0 = off 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0..15	0
5Fu 3	Return air sensor input (Temperature or Enthalpy): 0 = off, 1=UI1 to 8=UI8, 9=VI1 to 12=VI4	0..15	0
5Fu 4	If temperature sensors are used: Choose difference between outside air temperature and loop setpoint required to activate free heating or cooling. If enthalpy sensors are used: Choose difference between outside air enthalpy and return air enthalpy required to activate free heating or cooling Note: in order to prevent frequent activation / deactivation of mechanical heating or cooling, once conditions are met to activate free heating or cooling, only half the value of 5FU4 is required to maintain it.	Per input range	0
5Fu 5	Delay time to activate mechanical heating or cooling in case supply air set point cannot be reached through free heating or cooling.	00:00s...15:10h MM:SS...HH:MM	05:00 MM:SS
5Fu 6	Disable economizer in case one of the selected interlocks/alarms is active. The interlocks may be assigned to outdoor humidity or pollution sensors	Triangle shown = interlock selected	▽▽▽▽▽▽▽▽

- ➔ The aim of the economizer function is to reduce energy consumption by utilizing situations where cooling or heating requirements may be satisfied or supported by outdoor air.
- ➔ To operate, the economizer needs to be assigned to a control loop. There are several possibilities to determine if the condition for free heating or cooling is satisfied. The economizer operates differently depending on the sensors attached to it.
- ➔ Outdoor air enthalpy, return air enthalpy:
Once there is heating or cooling demand, the economizer compares the enthalpy of return air with outdoor air. If the minimum difference condition defined with 5FU4 is met, mechanical heating or cooling is deactivated and the outdoor and return air dampers are modulated to achieve the predefined set point of the supply air. Once free heating or cooling is activated, only half of 5FU4 is required to maintain it. Mechanical cooling will resume, if the set point is not reached during the time specified in 5FU5 or difference drops below 5FU4/2.
The outdoor damper will modulate based on demand, as long as the outdoor enthalpy is below the return air enthalpy for free cooling or above it for free heating.
- ➔ Outdoor air temperature, return air temperature:
Once there is heating or cooling demand, the economizer compares the setpoint with the outdoor air and return air temperature. If the minimum difference condition defined with 5FU4 is met, mechanical heating or cooling is deactivated and the outdoor and return air dampers are modulated to achieve the predefined set point of the supply air. Once free heating or cooling is activated, only half of 5FU4 is required to maintain it. Mechanical cooling will resume, if the setpoint is not reached during the time specified in 5FU5 or difference drops below 5FU4/2.
The outdoor damper will modulate based on demand, as long as the outdoor temperature is below the return air temperature for free cooling or above it for free heating.
With 5FU6 an interlock may be used to disable the economizer if the outdoor air humidity or outdoor air pollution is too high to provide free cooling.
- ➔ Outdoor air temperature only:
Once there is heating or cooling demand, the economizer compares the setpoint with the outdoor air temperature. If the minimum difference condition defined with 5FU4 is met, mechanical heating or cooling is deactivated and the outdoor and return air dampers are modulated to achieve the predefined set point of the supply air. Mechanical cooling will resume if the setpoint is not reached during the time specified in 5FU5.
With 5FU6 an interlock may be used to disable the economizer if the outdoor air humidity or outdoor air pollution is for too high to provide free cooling.

Modbus protocol

RTU or ASCII, data and stop bits

By default, RTU uses 8 data bits, 1 parity bit with even parity and 1 stop bit; ASCII mode uses 7 data bits, 1 parity bit with even parity, and 1 stop bit.

Both modes support "No Parity" mode, in these cases a 2nd stop bit is used to keep the byte length (11bit for RTU and 10 bit for ASCII, including the Start and Stop bits) unchanged in accordance with the Modbus specification. Other possible serial port modes like Odd Parity or baud rates other than listed ones are not supported.

Supported Modbus commands

- 03 (0x03): Read multiple registers
- 06 (0x06): Write single register
- 16 (0x10): Write multiple registers

In commands 03 and 16 the allowed number of registers ranges from 1 to 32. Although Modbus specification would allow more registers to be read and written, a maximum of 32 Modbus registers are supported in one packet. One Modbus register is 16 bits wide. The Modbus slave transmits the values as signed 16 bit integers. The least significant digit of the transmitted number is always the first digit below the decimal point, and this results in the following range of numbers that the slave module is able to transmit: from -9999.9 to 9999.9

In an event of an out-of-range command addressing or an unsupported command, the Modbus slave responds with an exception message according to the Modbus specification.

Communication configuration

Parameter	Address	Description	Range	Default
CO 00	13000	Bus plug-in id (read only)	0...255	1
CO 01	13001	Bus plug-in software version (read only)	0...255	-
CO 02	13002	Bus plug-in software revision (read only)	0...255	-
CO 03	13003	Communication address (must be unique in network)	1...127	1
CO 04	13004	Baud rate: 0 = 19200 1 = 4800 2 = 9600 3 = 19200 4 = 38400	0...255	0
CO 05	13005	Parity mode 0 = NO Parity, 2 stop bits 1 = EVEN Parity, 1 stop bit 2 = ODD Parity, 1 stop bit	0...255	1
CO 06	13006	Mode of communication 0 = RTU, 8 data bits 1 = ASCII, 7 data bits	0...255	0
CO 07	13007	Allow changing of static settings through communication 0 = Not allowed 1 = Allowed	0...255	1
CO 08	13008	Modbus address base mode 0 = Modbus addresses are "Base 0" 1 = Modbus addresses are "Base 1" (PLC style)	0...255	0
CO 09	13009	User definable data storage address 00	0...255	255
CO 10	13010	User definable data storage address 01	0...255	255
CO 11	13011	User definable data storage address 02	0...255	255
CO 12	13012	User definable data storage address 03	0...255	255
CO 13	13013	Not used	0...255	255
CO 14	13014	Not used	0...255	255
CO 15	13015	Automatic address increase. If enabled the address will automatically increase when parameters are automatically loaded at power up using AEC-PM1 in auto load mode. This is useful when setting up controllers for a large network. This way the installer will not have to login manually and set the network address for each controller. 0 = Auto increment function disabled 1 = Auto increment function is enabled	0...1	0

→ **Automatic address increase function:**

When this function is enabled and an automatic AEC-PM1 parameter load is executed at power up of the controller, the communication address on CO03 is incremented and written back to the AEC-PM1 unit. It is incremented only if the value is not already 127.

→ **Changing address register through broadcast message:**

It is not possible to change network address register through broadcast message.

Changing parameters of the controller through bus communication

It is possible to remotely changing parameters through an indirect read/write mode. Find details on the procedure required and how to interpret values in the application note: Access to control parameters through AEX-MOD

Dynamic Address list

Controller information

Address	Description	Range	R/W
1000	Product series information	8Bit	R
1001	Product type information	8Bit	R
1002	Controller Firmware Version	8bit	R
1003	Controller Firmware Revision	8bit	R
1004	Type of controller	16bit	R
1005	Number of control loops	16bit	R
1006	Number of binary inputs	16bit	R
1007	Number of universal inputs	16bit	R
1008	Number of virtual inputs	16bit	R
1009	Number of binary outputs	16bit	R
1010	Number of analog outputs	16bit	R
1011	Number of fan outputs	16bit	R
1012	Number of floating outputs	16bit	R
1013	Number of alarms	16bit	R
1014	Number of auxiliary functions	16bit	R
1015	Number of time schedules	16bit	R
1016	Number of switching times / time schedule	16bit	R

Controller state

1050	Operation State ON 0 = OFF, 1 = ON	1bit	R/W
1051	Operation state Standby – Comfort 0 = Comfort , 1 = Standby	1bit	R/W
1052	Operation State Heat – Cool 1 = Heat , 0 = Cool	1bit	R/W
1053	Operation state Celsius – Fahrenheit 0 = Celsius , 1 = Fahrenheit	1bit	R/W
1054	Operation state Fan Only 0 = Fan Only disabled 1 = Fan Only enabled	1bit	R/W
1055	Operation state Enable Time Schedules 0 = Time Schedules disabled 1 = Time Schedules enabled	1bit	R/W

Clock setting

1080	Century (0...99)	BCD format	R/W
1081	Year (0...99)	BCD format	R/W
1082	Month (1...12)	BCD format	R/W
1083	Day (1...31)	BCD format	R/W
1084	Weekday (1...7)	BCD format	R/W
1085	Hour (00...23)	BCD format	R/W
1086	Minute (00...59)	BCD format	R/W
1087	Second (00...59)	BCD format	R/W

Special controller flags

2022	No-reply-mode: No-reply-mode allows connecting one operation terminal to multiple controllers. One controller must be in normal operation mode and all the others must be set to no-reply-mode. These controllers will follow each command issued by the operation terminal. They will not send responses and their alarm conditions are not monitored by the operation terminal. 0 = normal operation , 1 = no-reply-mode	1bit	R/W
2023	Wink function: activates LED on top of controller 0 = LED has normal operation , 1 = LED is constantly on	1bit	R/W
2024	Operation state Summer – Winter (used to switch set point limits for 4-pipe systems) 0 = Summer mode 1 = Winter mode	1bit	R/W

Universal Inputs

Address	Input	Description	Range	Datatype	R/W
1100	UI1	universal input 1 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1101	UI1	Unit of universal input 0 = no unit 1 = % 2 = °C / °F 3 = Pa	8bit	16 bit signed	R
1102	UI1	Value Multiplier: "1" means a multiplication factor of 0.1 "10" means a multiplication factor of 1 "100" means a multiplication factor of 10	8bit	16 bit signed	R
1103	UI1	Short value (word)	16bit	16 bit signed	R
1700	UI1	Long value low word	16bit	32 bit signed	R
1701	UI1	Long value high word	16bit	(long inverse)	R
1104	UI2	universal input 2 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1105	UI2	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1106	UI2	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1107	UI2	Value	16bit	16 bit signed	R
1702	UI2	Long value low word	16bit	32 bit signed	R
1703	UI2	Long value high word	16bit	(long inverse)	R
1108	UI3	universal input 3 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1109	UI3	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1110	UI3	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1111	UI3	Value	16bit	16 bit signed	R
1704	UI3	Long value low word	16bit	32 bit signed	R
1705	UI3	Long value high word	16bit	(long inverse)	R
1112	UI4	universal input 4 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1113	UI4	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1114	UI4	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1115	UI4	Value	16bit	16 bit signed	R
1706	UI4	Long value low word	16bit	32 bit signed	R
1707	UI4	Long value high word	16bit	(long inverse)	R
1116	UI5	universal input 5 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1117	UI5	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1118	UI5	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1119	UI5	Value	16bit	16 bit signed	R
1708	UI5	Long value low word	16bit	32 bit signed	R
1709	UI5	Long value high word	16bit	(long inverse)	R
1120	UI6	universal input 6 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1121	UI6	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1122	UI6	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1123	UI6	Value	16bit	16 bit signed	R
1710	UI6	Long value low word	16bit	32 bit signed	R
1711	UI6	Long value high word	16bit	(long inverse)	R
1124	UI7	universal input 7 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1125	UI7	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1126	UI7	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1127	UI7	Value	16bit	16 bit signed	R
1712	UI7	Long value low word	16bit	32 bit signed	R
1713	UI7	Long value high word	16bit	(long inverse)	R
1128	UI8	universal input 8 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1129	UI8	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1130	UI8	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1131	UI8	Value	16bit	16 bit signed	R
1714	UI8	Long value low word	16bit	32 bit signed	R
1715	UI8	Long value high word	16bit	(long inverse)	R

Virtual Inputs

Address	Input	Description	Range	Datatype	R/W
1132	VI1	universal input 9 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1133	VI1	Unit of universal input (explanation as in 1101)	8 bit	16 bit signed	R
1134	VI1	Value Multiplier (explanation as in 1102)	8 bit	16 bit signed	R
1135	VI1	Value	16 bit	16 bit signed	R/W
1716	VI1	Long value low word	16 bit	32 bit signed	R
1717	VI1	Long value high word	16 bit	(long inverse)	R
1136	VI2	universal input 10 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1137	VI2	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1138	VI2	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1139	VI2	Value	16bit	16 bit signed	R/W
1718	VI2	Long value low word	16bit	32 bit signed	R
1719	VI2	Long value high word	16bit	(long inverse)	R
1140	VI3	universal input 11 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1141	VI3	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1142	VI3	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1143	VI3	Value	16bit	16 bit signed	R/W
1720	VI3	Long value low word	16bit	32 bit signed	R
1721	VI3	Long value high word	16bit	(long inverse)	R
1144	VI4	universal input 12 state, 0 = not active / error, 1 = ok	1bit	16 bit signed	R
1145	VI4	Unit of universal input (explanation as in 1101)	8bit	16 bit signed	R
1146	VI4	Value Multiplier (explanation as in 1102)	8bit	16 bit signed	R
1147	VI4	Value	16bit	16 bit signed	R/W
1722	VI4	Long value low word	16bit	32 bit signed	R
1723	VI4	Long value high word	16bit	(long inverse)	R

- ➔ The TCX2 can operate with external inputs. To activate, program the virtual input to use it as external input of the communication module: for example 9u00 = 2 (Address 3800 = 2) or 10u00 = 2 (Address 3900 = 2), see static address list on page 8).
- ➔ Then program the master to write to the input address the value to the corresponding input. For example Address 1135 for virtual input 1 and 1139 for virtual input 2. Observe the specified time out limitations in the virtual input settings of the TCX2. If the input is not re-written within the time out limits, the TCX2 will disable the corresponding virtual input and with it all associated control functions.

Control loop

Address	Loop	Description	Range	R/W
1200	Loop 1	Control input state	8bit	R
1201	Loop 1	Control loop sequence 1 = heating, 0 = cooling	1bit	R
1202	Loop 1	Control input unit	8 bit	R
1203	Loop 1	Control input value	16bit	R
1204	Loop 1	Saved Set point	8bit	R/W
1205	Loop 1	Calculated Set point	8bit	R
1206	Loop 1	Proportional output	8bit	R
1207	Loop 1	Binary output	8bit	R
1208	Loop 2	Control input state	8bit	R
1209	Loop 2	Control loop sequence 1 = heating, 0 = cooling	1bit	R
1210	Loop 2	Control input unit	8 bit	R
1211	Loop 2	Control input value	16bit	R
1212	Loop 2	Saved Set point	8bit	R/W
1213	Loop 2	Calculated Set point	8bit	R
1214	Loop 2	Proportional output	16bit	R
1215	Loop 2	Binary output	8bit	R
1216	Loop 3	Control input state	8bit	R
1217	Loop 3	Control loop sequence 1 = heating, 0 = cooling	1bit	R
1218	Loop 3	Control input unit	8 bit	R
1219	Loop 3	Control input value	16bit	R
1220	Loop 3	Saved Set point	8bit	R/W
1221	Loop 3	Calculated Set point	8bit	R
1222	Loop 3	Proportional output	16bit	R
1223	Loop 3	Binary output	8bit	R
1224	Loop 4	Control input state	8bit	R
1225	Loop 4	Control loop sequence 1 = heating, 0 = cooling	1bit	R
1226	Loop 4	Control input unit	8 bit	R
1227	Loop 4	Control input value	16bit	R
1228	Loop 4	Saved Set point	8bit	R/W
1229	Loop 4	Calculated Set point	8bit	R
1230	Loop 4	Proportional output	16bit	R
1231	Loop 4	Binary output	8bit	R

Analog Outputs

1300	AO1	State bit 0: 0 = not active / error, 1 = ok bit 1: 0 = automatic mode, 1 = manual mode	8bit	R
1301	AO1	Current value	16bit	R
1302	AO1	Override value (Only applies if output set to manual)	16bit	R/W
1303	AO2	State, 0 = not active / error, 1 = ok	8bit	R
1304	AO2	Current value	16bit	R
1305	AO2	Override value (Only applies if output set to manual)	16bit	R/W
1306	AO3	State, 0 = not active / error, 1 = ok	8bit	R
1307	AO3	Current value	16bit	R
1308	AO3	Override value (Only applies if output set to manual)	16bit	R/W

Digital Outputs

Address	DO	Description	Range	R/W
1400	DO1	State Bit 0: 0 = Floating mode is OFF, 1 = Floating mode is ON Bit 1: 0 = not active / error, 1 = active and ok Bit 2: 0 = automatic mode, 1 = manual mode Bit 3: 0 = PWM not active, 1 = PWM active Bit 6: 0 = Run time totalizer disabled, 1 = Run time totalizer ON Bit 7: 0 = Run time limit not reached, 1 = Run time limit reached Bit 3 to 7 only apply if bit 0 = 0 (non floating output)	8bit	R
1401	DO1	Current value	8bit	R
1402	DO1	Override value (Only applies if output set to manual)	8bit	R/W
1403	DO2	State, as on 1400	8bit	R
1404	DO2	Current value	8bit	R
1405	DO2	Override value (Only applies if output set to manual)	8bit	R/W
1406	DO3	State, as on 1400	8bit	R
1407	DO3	Current value	8bit	R
1408	DO3	Override value (Only applies if output set to manual)	8bit	R/W
1409	DO4	State, as on 1400	8bit	R
1410	DO4	Current value	8bit	R
1411	DO4	Override value (Only applies if output set to manual)	8bit	R/W
1412	DO5	State, as on 1400	8bit	R
1413	DO5	Current value	8bit	R
1414	DO5	Override value (Only applies if output set to manual)	8bit	R/W
1415	DO6	State, as on 1400	8bit	R
1416	DO6	Current value	8bit	R
1417	DO6	Override value (Only applies if output set to manual)	8bit	R/W

Fans

1500	FAN1	State Bit 0/1: = Current fan output Bit 2: 0 = not active / error, 1 = active and ok Bit 3: automatic mode, 1 = manual mode Bit 4/5: = Total number of fan speeds Bit 6: 0 = Fan mode active, 1 = rotation mode is active Bit 7: 0 = Manual fan off disabled, 1 = Manual fan off enabled	8bit	R
1501	FAN1	Current value	1bit	R
1502	FAN1	Override value	16bit	R/W
1503	FAN2	State, 0 = not active / error, 1 = ok	8bit	R
1504	FAN2	Current value	1bit	R
1505	FAN2	Override value	16bit	R/W

Alarms

1600	ALA1	Alarm active 0 = not active, 1 = active	1bit	R
1601	ALA1	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*
1602	ALA2	Alarm active 0 = not active, 1 = active	1bit	R
1603	ALA2	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*
1604	ALA3	Alarm active 0 = not active, 1 = active	1bit	R
1605	ALA3	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*
1606	ALA4	Alarm active 0 = not active, 1 = active	1bit	R
1607	ALA4	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*
1608	ALA5	Alarm active 0 = not active, 1 = active	1bit	R
1609	ALA5	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*
1610	ALA6	Alarm active 0 = not active, 1 = active	1bit	R
1611	ALA6	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*
1612	ALA7	Alarm active 0 = not active, 1 = active	1bit	R
1613	ALA7	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*
1614	ALA8	Alarm active 0 = not active, 1 = active	1bit	R
1615	ALA8	Alarm confirmed, 0 = confirmed, 1 = not confirmed	1bit	R/W*

*) Writable to 0 = confirmed only if state is 1 = not confirmed;